



OWNER'S MANUAL

EPA
DIRT BIKE
S8-KE300 / DB-K029

Dear user,

We would like to express our sincerest gratitude to you for choosing X-PRO Motorcycle. As a company dedicated to providing high-quality motorcycles, we are honored to offer you premium products and services.

Regarding the manual,

Before starting your brand-new X-PRO vehicle, please read this manual carefully. Here you will find detailed instructions on important operations of the vehicle. In combination with detailed assembly videos, you can make full use of X-PRO's technological advantages. We understand that buying a motorcycle is not only a consumption, but also a choice of lifestyle. Therefore, we have been continuously researching and improving our products, striving to provide you with a superior driving experience.

For Assembly video and Troubleshooting Tips,

please visit below link or scan the QR code below with your mobile phone.
tinyurl.com/xpro224



Once again, we thank you for your trust and support in X-PRO, and we look forward to establishing a long-term cooperative relationship with you, bringing you more premium products and services.

Wish you a pleasant ride!

X-PRO

IMPORTANT
PLEASE READ THIS MANUAL CAREFULLY AND COMPLETELY BEFORE GOING ON YOUR FIRST RIDE. IT CONTAINS A GREAT DEAL OF INFORMATION AND ADVICE WHICH WILL HELP YOU USE AND HANDLE YOUR BIKE PROPERLY.

Please write the serial numbers of your motorcycle in the boxes below

Chassis (VIN) Number	
Engine Number	
Key Number (If Available)	
Dealer Stamp	

CONSUMER INFORMATION FOR UNITED STATES
Tampering with noise & emissions control systems is prohibited

Owners are warned that the law prohibits:
A. The removal or rendering inoperative by any person other than for purposes of maintenance, repair or replacement, of any device or element of design incorporated into any new vehicle for noise and/or emissions control prior to its sale or delivery to the ultimate purchaser or while it is in use; and
B. The use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

we reserves the right to modify any equipment, technical specifications, colors, materials, services offered and rendered, and the like so as to adapt them to local conditions without previous announcement and without giving reasons, or to cancel any of the above items without substituting them with others. It shall be acceptable to stop manufacturing a certain model without prior notice. In the event of such modifications, please ask your local dealer for information.

LIMITED WARRANTY

WHAT IS COVERED :we warrants that this product is free of defects in material and workmanship.

➤ **PLEASE REFERENCE YOUR WARRANTY AND SERVICE BOOKLET FOR MORE INFORMATION**

TO GET SERVICE: Contact your nearest service center and/or dealer. The cost of transportation of the product to and from the service center and/or dealer must be paid by the owner.

No service center and/or dealer is authorized to modify this warranty.

CONTENTS

IMPORTANT WARRANTY INFORMATION	04	SUSPENSION SYSTEM	53-58
INTRODUCTION	06	SUSPENSION INSPECTION	53
DIRTBIKE SPECIFICATIONS	07-10	FRONT SUSPENSION ADJUSTMENT	54-55
IMPORTANT SAFETY INFORMATION	11-13	REAR SUSPENSION INSPECTION	56
SAFETY LABEL INFORMATION	14-15	REAR SUSPENSION ADJUSTMENT	57-58
COMPONENT LOCATIONS	16-17	RIMS, TIRES & SPOKES	59-60
SERIAL NUMBER LOCATIONS	18	TIRE INSPECTION	59
HANDLE BAR LEVER CONTROLS	18	TIRE AIR PRESSURE	59
OPERATING CONTROLS	19-21	TIRE AND TUBE REPLACEMENT	60
EFI SYSTEM	22-29	DRIVE CHAIN SYSTEM	61-65
BEFORE RIDING	30	DRIVE CHAIN INSPECTION	61
IS THE MOTORCYCLE READY TO RIDE	31	DRIVE SPROCKET INSPECTION	62
PRE-RIDE INSPECTION	31	CHAIN ROLLER INSPECTION	62
BASIC OPERATION & RIDING	32-33	CHAIN SLIDER INSPECTION	63
SAFE RIDE PRECAUTIONS	32	CHAIN ADJUSTMENT	64
ENGINE STARTING PROCEDURE	32	CHAIN LUBRICATION	64
FLOODED ENGINE	33	CHAIN REMOVAL & REPLACEMENT	65
STOPPING THE ENGINE	33	TROUBLESHOOTING	66-72
SHIFTING GEARS	34	RESOLVING THE UNEXPECTED	73-74
BRAKING TECHNIQUE	35	WIRING HARNESS	75
PARKING & POST RIDE INSPECTION	35	EMISSION CONTROL SYSTEM WARRANTY	76-78
MAINTAINING YOUR DIRT BIKE	36		
IMPORTANT SAFETY PRECAUTIONS	36		
MAINTENANCE SCHEDULE	37-39		
BASIC MAINTENANCE PRECEDURES	40-65		
FUEL, GASOLINE	40		
REFUELING & INSPECTION	40		
ENGINE OIL	41		
CHECKING & ADDING OIL	41		
CHANGING OIL & FILTER	42		
CHANGING / CLEANING AIR FILTER	43-45		
THROTTLE SYSTEM	46		
CLUTCH LEVER & CABLE ADJUSTMENT	47		
SPARK PLUG	48-49		
BRAKING SYSTEM	50-52		
BRAKE ADJUSTMENT	50		
BRAKE FLUID CHECK	50		
ADDING BRAKE FLUID	51		
BRAKE PADS	52		
BRAKE SYSTEM BLEEDING	52		

INTRODUCTION

Congratulations on choosing your off road motorcycle.

Your dirt bike was designed as a recreational motorcycle for off-road use only by a single rider only. This motorcycle is ideal for riders with basic experience.

Before riding, take plenty of time to get acquainted with your motorcycle and how it works. To protect your investment, we urge you to keep your motorcycle well maintained. In addition to regular maintenance, it is just as important to observe and perform all pre-ride and periodic checks detailed in this manual. We also recommend that you read this manual before you begin riding. In this manual you will find safety information, facts, instructions, helpful tips and illustrations. To make it easy to use, the manual contains a table of contents at the beginning of the manual.

As you read through this manual, you will find information that is preceded by a **NOTICE** symbol. This information is intended to help you avoid damage to your motorcycle and/or property around you. This manual covers basic maintenance procedures. A detailed parts diagram manual is available, and it can be purchased separately from Zuumav. The parts manual will be helpful to those with the mechanical skills and tools required to service their own motorcycle.

Whenever you ride, tread lightly. By staying on established trails and riding in approved areas, you will help protect the environment and keep off-road riding areas open for future use.

If you have any questions or you need any special service or repair, remember that your dealer knows your motorcycle best and will be dedicated to your complete satisfaction. Replacement parts and technical support can be obtained through your dealer. Please be sure to register your motorcycle with **us** and report any address changes so that we may contact you in the future concerning important product information.

300CC OFF- HIGHWAY MOTORCYCLE SPECIFICATIONS

K8-NC300 SPECIFICATIONS

Vehicle	Off-Highway Motorcycle	Model	K8-NC300
Fuel Type(s)	Gasoline	Dimension(mm)(LXWxH)	2180x830x1265 mm
Engine Type	4-Stroke ,1-cylinder, Liquid Cooled	Wheel Base(mm)	1515 mm
Engine Displacement(s)	298 CC	Ground Clearance(mm)	310 mm
Bore x Stroke	84×53.6mm	Seat Height(mm)	960 mm
Max Power	19.5/9000 kw/r/min	Max load(kg)	200KGS
Max Torque	23.5 /7000 N.m/r/min	Tire Size(Front/Rear)	80/100-21 & 110/100-18;
Compression Ratio	11.6:1	Wheel Rim(Front/Rear)	Alloy & Alloy
Shift Type	Manual, 1-N-2-3-4-5-6, Six Gears;	Brake(Front/Rear)	Disc / Disc
Ignition Mode	PEI	Rear Brake Operation	Foot
Spark Plug	DENSO/U22ESR-N	Starting	Electric Start
Min.Fuel Consumption	≤354g/(kW·h)	Battery Capacity	12V5AH
Fuel octane index	91 minimum (unleaded gasoline)	Eclectic Fuel Injection	HPFIT EFI System

S8-NC300 SPECIFICATIONS

Vehicle	Off-Highway Motorcycle	Model	S8-NC300
Fuel Type(s)	Gasoline	Dimension(mm)(LXWxH)	2180x830x1265 mm
Engine Type	4-Stroke ,1-cylinder, Liquid Cooled	Wheel Base(mm)	1515 mm
Engine Displacement(s)	298 CC	Ground Clearance(mm)	310 mm
Bore x Stroke	84×53.6mm	Seat Height(mm)	960 mm
Max Power	19.5/9000 kw/r/min	Max load(kg)	200KGS
Max Torque	23.5 /7000 N.m/r/min	Tire Size(Front/Rear)	80/100-21 & 110/100-18;
Compression Ratio	11.6:1	Wheel Rim(Front/Rear)	Alloy & Alloy
Shift Type	Manual, 1-N-2-3-4-5-6, Six Gears;	Brake(Front/Rear)	Disc / Disc
Ignition Mode	PEI	Rear Brake Operation	Foot
Spark Plug	DENSO/U22ESR-N	Starting	Electric Start
Min.Fuel Consumption	≤354g/(kW·h)	Battery Capacity	12V5AH
Fuel octane index	91 minimum (unleaded gasoline)	Eclectic Fuel Injection	HPFIT EFI System

K7-NC300 SPECIFICATIONS

Vehicle	Off-Highway Motorcycle	Model	K7-NC300
Fuel Type(s)	Gasoline	Dimension(mm)(LXWxH)	2170x800x1270 mm
Engine Type	4-Stroke ,1-cylinder, Liquid Cooled	Wheel Base(mm)	1480 mm
Engine Displacement(s)	298 CC	Ground Clearance(mm)	320 mm
Bore x Stroke	84×53.6mm	Seat Height(mm)	940 mm
Max Power	19.5/9000 kw/r/min	Max load(kg)	200KGS
Max Torque	23.5 /7000 N.m/r/min	Tire Size(Front/Rear)	80/100-21 & 110/100-18;
Compression Ratio	11.6:1	Wheel Rim(Front/Rear)	Alloy & Alloy
Shift Type	Manual, 1-N-2-3-4-5-6, Six Gears;	Brake(Front/Rear)	Disc / Disc
Ignition Mode	PEI	Rear Brake Operation	Foot
Spark Plug	DENSO/U22ESR-N	Starting	Electric Start
Min.Fuel Consumption	≤354g/(kW·h)	Battery Capacity	12V6.5AH
Fuel octane index	91 minimum (unleaded gasoline)	Eclectic Fuel Injection	HPFIT EFI System

300CC OFF- HIGHWAY MOTORCYCLE SPECIFICATIONS

K8-NB300 SPECIFICATIONS			
Vehicle	Off-Highway Motorcycle	Model	K8-NB300
Fuel Type(s)	Gasoline	Dimension(mm)(LXWxH)	2180x830x1265 mm
Engine Type	4-Stroke ,1-cylinder, Liquid Cooled	Wheel Base(mm)	1515 mm
Engine Displacement(s)	279.6CC	Ground Clearance(mm)	310 mm
Bore x Stroke	74×65mm	Seat Height(mm)	960 mm
Max Power	19/8500 kw/r/min	Max load(kg)	200KGS
Max Torque	24 /7500 N.m/r/min	Tire Size(Front/Rear)	80/100-21 & 110/100-18;
Compression Ratio	10.7:1	Wheel Rim(Front/Rear)	Alloy & Alloy
Shift Type	Manual, 1-N-2-3-4-5-6, Six Gears;	Brake(Front/Rear)	Disc / Disc
Ignition Mode	PEI	Rear Brake Operation	Foot
Spark Plug	DENSO_U24ESR-NB	Starting	Electric Start
Min.Fuel Consumption	≤354g/(kW·h)	Battery Capacity	12V5AH
Fuel octane index	91 minimum (unleaded gasoline)	Ecletic Fuel Injection	HPFIT EFI System

S8-NB300 SPECIFICATIONS			
Vehicle	Off-Highway Motorcycle	Model	S8-NB300
Fuel Type(s)	Gasoline	Dimension(mm)(LXWxH)	2180x830x1265 mm
Engine Type	4-Stroke ,1-cylinder, Liquid Cooled	Wheel Base(mm)	1515 mm
Engine Displacement(s)	279.6CC	Ground Clearance(mm)	310 mm
Bore x Stroke	74×65mm	Seat Height(mm)	960 mm
Max Power	19/8500 kw/r/min	Max load(kg)	200KGS
Max Torque	24 /7500 N.m/r/min	Tire Size(Front/Rear)	80/100-21 & 110/100-18;
Compression Ratio	10.7:1	Wheel Rim(Front/Rear)	Alloy & Alloy
Shift Type	Manual, 1-N-2-3-4-5-6, Six Gears;	Brake(Front/Rear)	Disc / Disc
Ignition Mode	PEI	Rear Brake Operation	Foot
Spark Plug	DENSO_U24ESR-NB	Starting	Electric Start
Min.Fuel Consumption	≤354g/(kW·h)	Battery Capacity	12V5AH
Fuel octane index	91 minimum (unleaded gasoline)	Ecletic Fuel Injection	HPFIT EFI System

K8-CBS300 SPECIFICATIONS			
Vehicle	Off-Highway Motorcycle	Model	K8-CBS300
Fuel Type(s)	Gasoline	Dimension(mm)(LXWxH)	2180x830x1265 mm
Engine Type	4-Stroke ,1-cylinder, Liquid Cooled	Wheel Base(mm)	1515 mm
Engine Displacement(s)	279.6CC	Ground Clearance(mm)	310 mm
Bore x Stroke	74×65mm	Seat Height(mm)	960 mm
Max Power	18.5/8500 kw/r/min	Max load(kg)	200KGS
Max Torque	23 /7500 N.m/r/min	Tire Size(Front/Rear)	80/100-21 & 110/100-18;
Compression Ratio	10.7:1	Wheel Rim(Front/Rear)	Alloy & Alloy
Shift Type	Manual, 1-N-2-3-4-5-6, Six Gears;	Brake(Front/Rear)	Disc / Disc
Ignition Mode	PEI	Rear Brake Operation	Foot
Spark Plug	DENSO_U24ESR-NB	Starting	Electric Start
Min.Fuel Consumption	≤354g/(kW·h)	Battery Capacity	12V5AH
Fuel octane index	91 minimum (unleaded gasoline)	Ecletic Fuel Injection	HPFIT EFI System

300CC OFF- HIGHWAY MOTORCYCLE SPECIFICATIONS

S8-CBS300 SPECIFICATIONS

Vehicle	Off-Highway Motorcycle	Model	S8-CBS300
Fuel Type(s)	Gasoline	Dimension(mm)(LXWxH)	2180x830x1265 mm
Engine Type	4-Stroke ,1-cylinder, Liquid Cooled	Wheel Base(mm)	1515 mm
Engine Displacement(s)	279.6CC	Ground Clearance(mm)	310 mm
Bore x Stroke	74x65mm	Seat Height(mm)	960 mm
Max Power	18.5/8500 kw/r/min	Max load(kg)	200KGS
Max Torque	23 /7500 N.m/r/min	Tire Size(Front/Rear)	80/100-21 & 110/100-18;
Compression Ratio	10.7:1	Wheel Rim(Front/Rear)	Alloy & Alloy
Shift Type	Manual, 1-N-2-3-4-5-6, Six Gears;	Brake(Front/Rear)	Disc / Disc
Ignition Mode	PEI	Rear Brake Operation	Foot
Spark Plug	DENSO U24ESR-NB	Starting	Electric Start
Min.Fuel Consumption	≤354g/(kW·h)	Battery Capacity	12V5AH
Fuel octane index	91 minimum (unleaded gasoline)	Eclectic Fuel Injection	HPFIT EFI System

K7-CBS300 SPECIFICATIONS

Vehicle	Off-Highway Motorcycle	Model	K7-CBS300
Fuel Type(s)	Gasoline	Dimension(mm)(LXWxH)	2170x800x1270 mm
Engine Type	4-Stroke ,1-cylinder, Liquid Cooled	Wheel Base(mm)	1480 mm
Engine Displacement(s)	279.6CC	Ground Clearance(mm)	320 mm
Bore x Stroke	74x65mm	Seat Height(mm)	940 mm
Max Power	18.5/8500 kw/r/min	Max load(kg)	200KGS
Max Torque	23 /7500 N.m/r/min	Tire Size(Front/Rear)	80/100-21 & 110/100-18;
Compression Ratio	10.7:1	Wheel Rim(Front/Rear)	Alloy & Alloy
Shift Type	Manual, 1-N-2-3-4-5-6, Six Gears;	Brake(Front/Rear)	Disc / Disc
Ignition Mode	PEI	Rear Brake Operation	Foot
Spark Plug	DENSO U24ESR-NB	Starting	Electric Start
Min.Fuel Consumption	≤354g/(kW·h)	Battery Capacity	12V6.5AH
Fuel octane index	91 minimum (unleaded gasoline)	Eclectic Fuel Injection	HPFIT EFI System

K8-KE300 SPECIFICATIONS

Vehicle	Off-Highway Motorcycle	Model	K8-KE300
Fuel Type(s)	Gasoline	Dimension(mm)(LXWxH)	2180x830x1265 mm
Engine Type	4-Stroke ,1-cylinder, Liquid Cooled	Wheel Base(mm)	1515 mm
Engine Displacement(s)	292.4 CC	Ground Clearance(mm)	310 mm
Bore x Stroke	78x61.2mm	Seat Height(mm)	960 mm
Max Power	22.5/9000 kw/r/min	Max load(kg)	200KGS
Max Torque	25.5 /8500 N.m/r/min	Tire Size(Front/Rear)	80/100-21 & 110/100-18;
Compression Ratio	11.5:1	Wheel Rim(Front/Rear)	Alloy & Alloy
Shift Type	Manual, 1-N-2-3-4-5-6, Six Gears;	Brake(Front/Rear)	Disc / Disc
Ignition Mode	PEI	Rear Brake Operation	Foot
Spark Plug	TORCH B8RC	Starting	Electric Start
Min.Fuel Consumption	≤354g/(kW·h)	Battery Capacity	12V5AH
Fuel octane index	91 minimum (unleaded gasoline)	Eclectic Fuel Injection	HPFIT EFI System

300CC OFF- HIGHWAY MOTORCYCLE SPECIFICATIONS

S8-CBS300 SPECIFICATIONS			
Vehicle	Off-Highway Motorcycle	Model	S8-CBS300
Fuel Type(s)	Gasoline	Dimension(mm)(LXWxH)	2180x830x1265 mm
Engine Type	4-Stroke ,1-cylinder, Liquid Cooled	Wheel Base(mm)	1515 mm
Engine Displacement(s)	279.6CC	Ground Clearance(mm)	310 mm
Bore x Stroke	74×65mm	Seat Height(mm)	960 mm
Max Power	18.5/8500 kw/r/min	Max load(kg)	200KGS
Max Torque	23 /7500 N.m/r/min	Tire Size(Front/Rear)	80/100-21 & 110/100-18;
Compression Ratio	10.7:1	Wheel Rim(Front/Rear)	Alloy & Alloy
Shift Type	Manual, 1-N-2-3-4-5-6, Six Gears;	Brake(Front/Rear)	Disc / Disc
Ignition Mode	PEI	Rear Brake Operation	Foot
Spark Plug	DENSO U24ESR-NB	Starting	Electric Start
Min.Fuel Consumption	≤354g/(kW·h)	Battery Capacity	12V5AH
Fuel octane index	91 minimum (unleaded gasoline)	Eclectic Fuel Injection	HPFIT EFI System
S8-KE300 SPECIFICATIONS			
Vehicle	Off-Highway Motorcycle	Model	S8-KE300
Fuel Type(s)	Gasoline	Dimension(mm)(LXWxH)	2180x830x1265 mm
Engine Type	4-Stroke ,1-cylinder, Liquid Cooled	Wheel Base(mm)	1515 mm
Engine Displacement(s)	292.4 CC	Ground Clearance(mm)	310 mm
Bore x Stroke	78×61.2mm	Seat Height(mm)	960 mm
Max Power	22.5/9000 kw/r/min	Max load(kg)	200KGS
Max Torque	25.5 /8500 N.m/r/min	Tire Size(Front/Rear)	80/100-21 & 110/100-18;
Compression Ratio	11.5:1	Wheel Rim(Front/Rear)	Alloy & Alloy
Shift Type	Manual, 1-N-2-3-4-5-6, Six Gears;	Brake(Front/Rear)	Disc / Disc
Ignition Mode	PEI	Rear Brake Operation	Foot
Spark Plug	TORCH B8RC	Starting	Electric Start
Min.Fuel Consumption	≤354g/(kW·h)	Battery Capacity	12V5AH
Fuel octane index	91 minimum (unleaded gasoline)	Eclectic Fuel Injection	HPFIT EFI System

IMPORTANT SAFETY INFORMATION

Your personal safety, and the safety of those around you, is extremely important. Operating this motorcycle safely is an important responsibility. Zuumav has provided operating procedures and other information on labels and in this manual to help you make informed decisions about safety. This information will alert you to potential hazards that could harm you or others.

It is understood that it is not practical or possible to warn you about all possible hazards associated with operating and maintaining a motorcycle. You must use your own good judgment.

Safety information will come in a variety of different forms, including:

- ❖ Safety Labels on the Motorcycle.
- ❖ Safety Messages preceded by a safety symbol  and one of these signal words:

Below are the definitions of these three words:

 **DANGER** You WILL be KILLED or SERIOUSLY INJURED if you do not follow instructions.

 **WARNING** You CAN be KILLED or SERIOUSLY INJURED if you do not follow instructions.

 **CAUTION** You CAN be INJURED if you do not follow instructions.

- ❖ Safety Headings such as important safety reminders and/or precautions.
- ❖ Safety Section such as motorcycle safety.
- ❖ Instructions how to use the motorcycle safely and correctly.

This entire manual is filled with important safety information - please read it carefully.

IMPORTANT SAFETY INFORMATION

A motorcycle can provide many years of service and pleasure, provided you take responsibility for safety, properly maintain your motorcycle and understand the challenges you may encounter while riding.

This motorcycle has been designed for younger riders. However, not all youngsters meet the physical and emotional levels that are needed for riding. Before parents allow any children to ride this motorcycle, we strongly recommend that they read this entire manual so that they are fully informed before deciding if their children are ready to ride. Listed below are some of the most important safety measures one should take when riding.

⚠ DANGER Never Ride Without a Helmet. The following statement is a proven fact: "Helmets significantly reduce the number and severity of head injuries." Never ride your motorcycle without a helmet. Even a crash at slow speed can result in a fatal head injury if you are not wearing a helmet. Zuumav recommends wearing helmets that have been certified for safety by helmet testing organizations that are independent from the helmet manufacturer. We also recommend that you wear eye protection, boots, gloves, and other protective gear such as off-road riding pants.

⚠ WARNING Never Carry a Passenger. This motorcycle has been designed for ONE rider only. There are no passenger pegs, footrests, handles or seat room for a passenger. Riding with a passenger can interfere with your ability to operate and/or control the motorcycle and may result in serious injury or death.

⚠ WARNING Ride Off-Road Only. This motorcycle has been designed and manufactured for off-road use only. The motorcycle is not equipped with lights, turn signals, horn and other features required to drive a motorcycle on public roads. The tires are not designed for pavement and will make the motorcycle unstable if it is ridden on pavement. If you must cross a paved road, dismount and walk the motorcycle across the road.

⚠ WARNING Ride Within Your Limits. Never attempt to ride your motorcycle in a manner that is beyond your skill level. It takes time to learn off-road riding skills. Learn to ride your motorcycle step by step. Start by practicing on safe terrain at slow speeds and gradually build your skill level. Instruction from an experienced rider(s) is highly recommended. Remember that alcohol, drug use, fatigue and ignorance can reduce your ability to make good decisions and ride safely.

⚠ WARNING Be Alert for Hazards. The terrain in which you ride can present many hazards. Always "scan" the terrain ahead of you continually. Watch for un-expected turns, drop-offs, ditches, rocks and other hazards. Always maintain a speed slow enough to allow you enough time to see and react to hazards.

⚠ DANGER Do Not Drink and Ride. Even one drink can impair your ability to ride a motorcycle safely. Each drink afterward will make the impairment worse. Do not drink and ride. Do not let your friend's drink and ride. Remember, in most states throughout the United States, you can be arrested and charged with Driving Under the Influence (DUI) if you are riding a motorcycle while intoxicated. This applies to off-road motorcycles as well.

IMPORTANT SAFETY INFORMATION FOR PARENTS

As a parent, your child's safety is your first priority. Riding an off-road motorcycle is very fun. However, just like riding a bicycle, bad decisions can result in injury. As a parent, you can greatly prevent accidents by making informed decisions about if, when and how your child will ride. Always supervise your child when he/she is riding.

Before you allow your child to ride, you need to decide if he/she is capable of riding. Riding readiness can vary tremendously from one person to another. Age and size are not being the only factors that help determine one's riding readiness. There are three other factors that you should also consider before deciding if your child is ready to ride.

First, consider the **physical ability** of your child. Riders must be able to hold the motorcycle up, get on, and sit comfortably with both feet on the ground. The rider must also be able to reach all of the controls on the handlebars and work the brakes and clutch. Second, consider your child's **athletic ability**. Your child should be good at riding a bicycle before riding a motorcycle. Determine if your child can judge speeds and distances while riding a bicycle and react with the proper hand and foot actions. Any person who does not have good coordination, balance, and agility should not ride this motorcycle.

Finally, determine your child's level of **mental maturity**. It is imperative that you are honest with yourself when you ask yourself the following questions: Does your child think through problems and come to logical conclusions? Does your child obey your rules when they ride their bicycle? If your child makes bad judgments, takes un-warranted risks and/or does not obey your rules, they should not ride this motorcycle.

If you have decided that your child is ready to ride, please remember the following points and never let your child ride without a helmet. It is up to you (parent) to ensure your child's safety, even if they learn to ride from another experienced adult. Never push your child to try things faster than they are willing or capable. Always supervise your child when they are riding and regularly remind them about safety rules. As a parent it is your responsibility to be sure that the motorcycle is properly maintained and kept in safe operating condition.

Modifying this motorcycle or using parts not manufactured by us can make your motorcycle unsafe. Before you consider making any modifications or adding an accessory, please read the following information carefully.




Improper accessories or modifications can cause a crash in which you can be seriously hurt or killed. Follow all instructions in this owner's manual regarding modifications and accessories.

We strongly recommend that you do not remove any original equipment or modify your motorcycle in any way that may alter the design and/or operation. Such a change could drastically impair the stability, handling, acceleration, and braking capabilities of the motorcycle and cause a crash. We also strongly suggest that you do not make any modifications to the exhaust system components.

300CC DIRTBIKE SAFETY LABELS

This page will show you where to find the safety labels on your motorcycle. You will find that some labels warn you of potential hazards. Others will provide important safety and maintenance information. Please read them carefully and do not remove them. If your label wears off from riding or becomes hard to read, contact your dealer for a replacement.



SAFETY LABELS LOCATIONS



COMPONENT LOCATIONS

When you ride a motorcycle off-road, you need to be able to operate the throttle, clutch, brakes, and motorcycle. This section of the manual will describe the function, location, and operation of all the basic controls of your motorcycle.



COMPONENT LOCATIONS



SERIAL NUMBER LOCATIONS



VIN – Chassis Number

The VIN number is located on the neck of the chassis.

1. Right side of frame.

Write this number in the VIN box on Page 3.



Engine Model & Serial Number

The engine model number and serial numbers are stamped on the left side of the engine under the cylinder.


Write this number in the Engine Number box on page 3.

HANDLEBAR LEVER CONTROLS



Clutch Lever

The clutch lever **A** is located on the left side of the handlebar.



Hand Brake Lever & Throttle

The hand brake lever **A** and throttle **B** are mounted on the right side of the handlebar.

OPERATING CONTROLS



Stop Switch


The stop (kill) switch **A** turn off the engine. When this button is pressed, the ignition circuit is turned off.



Start Switch (Electric Start Engine)

The start switch **A** turns on the engine. When this button is pressed, the electric starter will engage to start the engine. Once started, release the button.

OPERATING CONTROLS




Key Switch (No Steering Lock)

The ignition key **A** is used to supply power from the battery to the electrical components of the motorcycle. Turn the switch to the "OFF" position **B** when you are finished riding, or if you wish to stop the engine.


B OFF position

C ON position



Key Switch (With Steering Lock) if applicable

The ignition key **A** is used to supply power for the battery to the electrical components of the motorcycle in the "ON" position **B**. Turn the switch to the "OFF" position **C** when you are finished riding, or if you wish to stop the engine.



Key Switch (Locking the Steering) if applicable

To lock the steering system, turn the key to the "OFF" position **A**, push and release the key, then rotate counter-clockwise to the "LOCK" position **B**.



Fuel Filler Cap

To Open: Turn the cap **A** counter-clockwise.

To Close: Turn the cap clockwise, make sure the breather tube **B** is installed.

OPERATING CONTROLS



Gear Shift Lever

The gear shift lever **A** is on the left side of the engine. The gear positions are shown in the illustration on the left. (6th gear is optional, depending on your engine).



Foot Brake Lever (Rear Brake)

The rear brake lever **A** is located on the right side of the engine near the foot rest. Its basic operation is to apply the rear brake to slow or stop the motorcycle.




Side (Kick) Stand

Push the side stand **A** to the ground and tilt the motorcycle to the left. Make sure the motorcycle is on solid ground and the position is secure.

Main Components EFI Fit

A set of EFI fit include ECU ,petrol pump,high–pressure pipe, ignition coil , throttle valve, intake air pressure sensor, fuel injector ,idle air supply motor or step–by–step motor, temperature sensor, crankshaft position sensor, throttle position sensor, oxygen sensor and wire.



Attachment 1

Number	Components	Main Function
1	ECU	Collect sensor data, process and control injection ignition through actuator
2	Fuel Pump	Supply stable-pressure petrol
3	Fuel Pipe	The fuel supply pressure of the injector is 2.5-3.8 atmospheres, and the oil circuit needs high pressure protection .
4	Ignition Coil	Dc ignition needs to be changed to inductive energy storage high voltage pack
5	Throttle Valve	Provide suitable intake air to the engine of the moving vehicle.
6	Air Pressure Sensor	The engine load is calculated together with the rotation speed, then the injection is adjusted.
7	Fuel Injector	Supply petrol to engine according to the instruction of

		ECU
8	Throttle Position Sensor (TPS)	Judge the driving condition, and adjust the fuel injection amount in time to provide additional fuel injection amount for rapid acceleration.
9	Idle Air-supply Or Step-by-step Motor	When starting, increase the intake gas to start easily and stabilize the engine idle speed.
10	Cylinder Temp Sensor	Adjust the injection and intake volume according to different temperature
11	Crankshaft Position Sensor	Determine the basic ignition and fuel injection time
12	Oxygen Sensor	According to the oxygen content in the tail gas, the injection amount can be adjusted to reduce the generation of engine combustion pollutants.
13	Wire	Supply power to the EFI system and connect the components.

Attachment 2 Fault symptoms of EFI parts

Number	Components	Fault Symptoms
1	ECU	I After power-on, the fault light will not turn on and cannot be started; II After power-on, the oil pump will not work, III The power pin of the pressure sensor is not 5V to the ground, so it cannot be started.
2	Fuel Pump	I Do not work, can not hear the sound of oil pump motor rotatio. II The oil pressure of high-pressure tubing is insufficient (less than 0.2Mpa), and the vehicle is difficult to start and promote.
3	Fuel Pipe	Oil leakage or filter blockage caused by insufficient oil pressure.
4	Ignition Coil	I Starting oil injection is normal, but there is no ignition, so it cannot be started. II Can start, idle speed is unstable but acceleration is weak.
5	Throttle Valve	I Air leakage, after starting the idle speed is very high; II Throttle pull wire does not return, after starting the idle speed is very high; III Improper adjustment of idle screw, low idle speed easy to stall and difficult to start.
6	Air Pressure Sensor	It can start normally, but flameout immediately; Or you can keep working but smoke while idling, can only drive slowly and unable to accelerate.

Attachment 2 Fault symptoms of EFI parts

7	Fuel Injector	I The injector has no oil injection and cannot be started; II The fuel injector is blocked, it is difficult to start, easy to stall while idle, and the vehicle is weak.
8	Idle Air-supply Or Step-by-step Motor	The gas supply does not work or is blocked, so it is difficult to start. It is necessary to pull the throttle to start; Cooling engine idle speed is lower than the heat engine; and Turning off the throttle is easy to stall when the engine is cold.
9	Cylinder Temp Sensor	It is difficult to start the cool engine below 10℃; 10-40℃ can start normally; It's hard to start a heat engine above 40℃; It is thicker after heating.
10	Crankshaft Position Sensor	I Failed to start; II After power on, wait until the oil pump stops running then start but the sound of oil pump re-running cannot be heard.
11	Oxygen Sensor	Normal operation, poor emission.
12	Wire	All the fault above. Please check the every plug.

Attachment 3 Common Faults

Common Faults	Possible causes	Solutions
Engine start difficulty	I No fuel in tank II No power in the battery III Fuel injector faulty IV ECU faulty V Insufficient pressure of pump VI Idle air-supply or step-by-step motor faulty VII Ignition trigger failure VIII No ignition	I Fill up II Charge, or start with foot (voltage >11V) III Replace new one IV Replace ECU V Replace pump VI Replace VII Replace VIII Replace high voltage pack or spark plug
Poor idle speed, abnormal sound or automatic extinguishing when starting or accelerating	I Air pressure sensor faulty II Poor contact of ignition trigger III Blockage of filter IV Insufficient pressure of the pump V Throttle body is leaking VI ECU faulty	I Replace II Clamp or replace the terminal III Replace IV Replace the pump V Replace VI Replace
The spark and fuel injection is normal, the engine is not working properly	There's water in the fuel.	Clean the fuel line

Attachment 3 Common Faults

High idle speed	I The throttle cable will not return II The intake pipe is leaking	I Replace II Replace III Replace
	III Idle air-supply or step-by-step motor fault	
Cold engine starting difficulty in low temperature	I Temperature fault II Idle motor fault III Non usage of winter oil IV The battery is out of power V The engine valve clearance is too small	I Replace II Replace III Replace winter oil IV Charge, or start with foot (voltage >11V) V Adjust
The engine stopped when you yanked the throttle	I TPS fault	I Replace TPS

Attachment 4 Fault Light Blinking

We also design to judge the fault by blinking times of fault light .

Step 1 Turn off the power to the key and remote control.

Step 2 Pull the throttle down and pause low for more than 3 seconds. Do not let go.

Step 3 Power on the keys.

Step 4 Read the total number of flashing lights in each cycle.

(For example, temperature sensor failure: 1 down pause 2 down pause 3 down pause 4 down pause 5 ---- down pause 3 seconds ---- 1 down pause 2 down pause 3 down pause 4 down pause 5 down pause ---- pause 3 seconds ---- infinite cycle), it can be judged that the total number of flashing lights in each cycle is 5.

1	Fuelinjector
2	Airpressuresensor
3	Oxygensensor
4	Pumprelay
5	Temperaturesensor
6	Idlemotor
7	TPS
8	Power
9	Thecrankshafttoothfailure

Attachment 5 Fault Code List

Fault Code	Fault Description	Reference
P0106	Fixed MAP signal	Fixed intake and exhaust stroke voltage<0.5V
P0107	Ultra-low MAP signal	The voltage is lower than 0.05V or disconnection
P0108	Ultra-high MAP signal	The voltage is over 4.85V
P0117	Ultra-low temperature sensor voltage	The voltage is lower than 0.22V
P0118	Ultra-high temperature sensor voltage	The voltage is over 4.97V or disconnection
P0122	Ultra-low TPS voltage	The voltage is lower than 0.3V
P0123	Ultra-high TPS voltage	The voltage is over 4.85V or short circuit
P0130	No desired signal of Oxygen sensor	Signal invariance (not active 30s-150s)
P0131	Ultra-low oxygen sensor signal	The voltage is lower than 0.02V
P0132	Ultra-high oxygen sensor signal	The voltage is over 4.85V
P0230	Pump relay fault:	Disconnection or short circuit
P0261	Fuel injector fault:	Disconnection or short circuit
P0505	Idle motor fault:	Disconnection or short circuit
P0650	Fault light malfunction	short circuit

BEFORE RIDING

Before you ride, you must be absolutely sure that you and your motorcycle are ready to ride. To help you get prepared, this section of the manual will discuss how to evaluate your riding readiness and how to perform our recommended ore-ride inspection of your motorcycle. If you are a parent, please be sure you have read the section "Important Safety Information for Parents" on page 9.

Are You Ready to Ride?

Before you ride your motorcycle for the first time, we strongly recommend the following:

1. Completely read this manual.
2. Be sure you have read and understand all the safety messages and labels.
3. You know how to operate all, of the motorcycle's controls.

Before each ride, we strongly recommend that you:

1. Are in good physical and mental condition.
2. Are free of alcohol and other drugs.
3. Are wearing an approved motorcycle helmet with a tight chin strap, eye protection and other protective clothing.

PROTECTIVE GEAR & APPAREL

For your safety, we strongly recommend that you always wear an approved helmet, eye protection, boots, gloves, long pants and a long sleeved, jersey shirt or jacket whenever you ride. Although complete protection is not possible, wearing the proper gear can reduce the chance of and severity of injuries when you ride.

Helmets & Eye Protection – Your helmet is your most important piece of riding gear because it offers the best protection against head injuries. A good helmet will be approved by a testing organization independent of the helmet manufacturer and will have a chin strap that can be tightened securely. Open-face helmets offer some protection, but a full-face helmet offers the most protection. When purchasing a helmet, regardless of style, look for DOT (Department of Transportation) sticker (USA only). If the helmet has been tested by an independent organization such as the Snell Institute, you will usually find their logo on a tag inside the padding of the helmet.

Additional Riding Gear – In addition to your helmet and eye protection, we also recommend:

1. Sturdy off-road motorcycle boots to help protect your feet, ankles and lower legs.
2. Off-Road motorcycle gloves to protect your hands.
3. Riding pants with knee and hip pads, a riding jersey with elbow pads and a chest/shoulder protector.

WARNING

NOT WEARING A HELMET INCREASES THE CHANCE OF SERIOUS INJURY OR DEATH IN A CRASH. BE SURE YOU ALWAYS WEAR YOUR HELMET AND OTHER PROTECTIVE APPAREL WHEN YOU RIDE.

IS THE MOTORCYCLE READY TO RIDE?

Before each, and every ride you take, it is extremely important that you inspect the motorcycle and make sure any problems you find are corrected. A pre-ride inspection is a must because off-road riding can be very tough on a motorcycle and you do not want to have a breakdown for from help.

WARNING

Improperly maintaining your motorcycle or failing to correct a problem before riding can cause a crash in which you can be seriously hurt or killed. Always preform a pre-ride inspection before any ride and correct any problems.

NOTICE TO PARENTS

If a youngster will be performing any of the following pre-ride inspection procedures, it is your responsibility to provide careful supervision and make sure they are performed safely.

PRE-RIDE INSPECTION

Check the following items before you get on the motorcycle:

Tires – Use a tire pressure gauge to check the air pressure. Inflate or deflate as needed. Also check for signs of damage or excessive wear.

Spokes & Rims – Make sure all of the spokes are tight. Inspect the rim to be sure it is not bent.

Leaks – Look under the motorcycle for signs of leaking fluids such as engine oil or gasoline.

Engine Oil – Check the level of engine oil and add if needed.

Fuel – Check the level of fuel in the gas tank. Add if needed. Be sure the gas cap is tightened securely.

Drive Chain – Inspect the drive chain condition and slack. Adjust and lubricate if needed. Also check the chain guide(s) and roller(s) for wear and replace if and when it is worn. For detailed instructions on drive chain slack adjustment, see the Servicing section of this manual.

Brake Hoses – Inspect the brake hoses for leaks and replace if needed.

Nuts & Bolts – Inspect all accessible nuts and bolts. Tighten then if it is needed.

Spark Plug & Cap – Check the spark plug for looseness. Tighten if needed. Be sure the cap is pushed on the spark plug and it is tight properly.

Check the following items after you get on the motorcycle:

Throttle – Check the throttle free-play and adjust if needed. Rotate the throttle to be sure it moves easily and freely. Make sure that it snaps back to its closed position automatically when you release it in all steering positions.

Brakes – Step on the rear brake lever and squeeze the front brake lever to be sure the brakes are working properly.

Remember, be sure to take care of any problems you find or have your Zuumav dealer correct it before you ride.

BASIC OPERATION & RIDING

This section of the manual gives basic information on how to begin riding your motorcycle. In this section we will cover how to start and stop the engine, how to use the throttle and brakes, how to use the clutch and shift gears, and things you need to do when you are finished riding.

To protect your new engine and enjoy optimum performance and service life, be sure to break-in your motorcycle properly. To do this, avoid full throttle starts and rapid acceleration for the first 35 miles (56 km) of riding.

SAFE RIDE PRECAUTIONS

Before riding this motorcycle, be sure you have read this entire manual up to this point including the section titled "Important Safety Information (Pg. 7, 8 & 9) & Before Riding".

Even if you have ridden other motorcycles in the past, take time to get familiar with the way the motorcycle works and handles. Always practice in a safe area until you have built your skill level to a point at which it is safe to ride.

CAUTION

For your safety, avoid starting or operating the motorcycle in an enclosed area with poor ventilation, such as a garage. The motorcycle's exhaust gas contains poisonous carbon monoxide which can collect rapidly in an enclosed area and result in illness or death.

WARNING

Your motorcycle is not equipped with lights. DO NOT ride at night.

STARTING & STOPPING THE ENGINE

Always follow the proper starting procedure as described below.

STARTING PROCEDURE (ELECTRIC START)

Starting When the Engine Is Cold

1. Turn the key switch to the "ON" position.
2. Make sure the transmission is in the neutral position.
3. Turn the fuel tap to the "ON" position.
4. Press and hold the brake lever on the right side of the handlebar
5. Open the throttle no more than 1/4 of the way
6. Press the start "yellow" (green) button until the engine starts.
7. Release the button as soon as the engine starts .
8. Wait until the engine warms up for approximately 5 minutes. After the 5 minutes warm up, you are ready to go.

Starting When the Engine Is Warm

Repeat steps 1, 2, 3, 6, 7, and 8 in section "Starting when the engine is cold".

FLOODED ENGINE

If the engine fails to start after repeated attempts, it may be flooded with excess fuel. Follow the steps below to clear a flooded engine.

1. Press the engine stop switch and hold it.
2. Open the throttle completely.
3. Press the engine start switch and hold it for 5 seconds. (Electric Start)
4. If necessary, remove the spark plug and let it dry.
5. Once the engine starts, open the throttle $\frac{1}{4}$ for a few times.

STOPPING THE ENGINE

To stop the engine, shift into neutral and push the engine stop switch **A** on the left side of the handle bar.



CAUTION

DO NOT ride your motorcycle with full load and DO NOT rev up the engine when cold. Since the piston warms up and expands faster than the liquid cooled cylinder, this might cause engine damage. Always let the engine idle until warm or ride it warm at low RPM speeds.

CAUTION


For your safety, avoid starting or operating the motorcycle in an enclosed area with poor ventilation, such as a garage. The motorcycle's exhaust gas contains poisonous carbon monoxide which can collect rapidly in an enclosed area and result in illness or death.

SHIFTING GEARS

This motorcycle has Six (6) forward gears.

To start riding, after the engine has been warmed up and the side stand raised:

1. Close the throttle and squeeze the clutch lever all the way in.
2. Depress the shift lever from neutral down to first gear. Once the transmission clicks into gear, the shift lever will return back to the neutral "N" position once you remove your foot.
3. Slowly and gradually open the throttle and release the clutch lever in a simultaneous motion. When you feel the clutch begin to grab and the motorcycle starts to ease forward, you have reached the "friction zone" of the clutch. Gradually open the throttle more and release the clutch lever completely as the motorcycle moves forward.
4. When you attain moderate speed, close the throttle and squeeze the clutch lever at the same time. Raise the shift lever until it clicks into second gear. After shifting, re-open the throttle and release the clutch lever.
5. To continue shifting up to each higher gear, repeat step 4.
6. To shift down to a lower gear, close the throttle and pull the clutch. Depress the shift lever until you feel it click into gear. After shifting, re-apply the throttle and release the clutch lever smoothly.



NOTICE

Remember to close the throttle before shifting gears. Improper shifting may damage the engine, transmission, and drive train.

Learning when to shift gears will come with riding experience. Up-shift into a higher gear when you hear the engine speed (rpm) get too high. When the engine rpm gets too high in a gear, you will feel the motorcycle stop accelerating. This is another way to know when to up-shift.

Downshift to a lower gear when you feel the engine lugging at a low rpm. Downshifting is usually done when you slow down for a turn or when you stop the motorcycle. Downshifting into a lower gear can help slow down your motorcycle, especially when going down-hill. However, down shifting when the engine rpm is too high can cause engine damage.

The neutral position of the transmission is located between the first and second gear positions. To shift into neutral, pull the clutch lever in and depress the shift lever as many times as needed to get into first gear. Once you are in first gear, pull up on the shift lever $\frac{1}{2}$ the distance required to up-shift into second gear. You can also shift into neutral from second gear by depressing the shift lever $\frac{1}{2}$ the distance required to downshift into first gear.

To prevent transmission damage, do not coast or tow the motorcycle for long distances with engine off.

WARNING

Never attempt to start the engine in gear. Doing so may cause a crash that could result in serious injury or death.

BRAKING TECHNIQUE

This section will cover basic braking technique for your motorcycle. To slow or stop the motorcycle, squeeze and hold the clutch lever and apply the front brake lever and rear brake pedal firmly and smoothly. If your speed is reduced a significant amount, you may need to downshift to a lower gear. Gradually increase your braking pressure as you feel it is needed. When you come to a stop, put your left foot down first, then the right foot. Do this so that your brake pedal foot remains on the brake pedal until you come to a complete stop. To prevent the engine from stalling, always pull and hold the clutch lever when slowing to a complete stop unless you are in neutral.

For maximum braking, close the throttle and firmly apply both the front and rear brake. On a motorcycle, the front brake accounts for 70% of the total stopping power of the motorcycle. The rear brake only accounts for 30%. This is because of the weight transfer that occurs when you apply the brakes. When you must stop quickly, you must use the front brake together with the rear brake. Remember that you can apply more brake to the front wheel than you can to the rear wheel before it will lock up and cause a skid. Finding the proper balance between the amount of front and rear brake pressure you use will come with experience. Attempting an abrupt stop with only the rear brake will likely cause a skid.

Applying the brakes too hard or too fast can cause the wheels to lock and cause a skid, reducing your control of the motorcycle. If this happens, release the brake controls and steer straight ahead until you regain control of the motorcycle. Once you have control, reapply the brakes with less force.

Generally, reduce your speed and complete your braking before you begin a turn. Avoid braking or closing the throttle quickly while turning. Either of these actions may cause one or both of the wheels to slip. Any wheel slip will reduce your control over the motorcycle and could cause a crash. When riding in wet or rainy conditions, or on loose surfaces such as mud or sand, your ability to maneuver and stop the motorcycle will be reduced. All of your actions should be done in a smooth and steady manner under these conditions. Rapid acceleration, braking, or turning can cause you to lose control of the motorcycle. For your safety, exercise extreme caution when riding under wet, rainy, and/or muddy conditions.

When descending a long, steep grade, use engine compression braking by downshifting with intermittent use of both brakes.

PARKING & POST RIDE INSPECTION

Lower the side stand, to support your motorcycle. Press and hold the red stop switch on the left side of the handle bar until your engine stops. If you are through riding for the day, turn the fuel valve to the "OFF" position. Always park the motorcycle on a flat level surface. If you will be storing the motorcycle for a long period of time, turn the fuel valve to the "OFF" position while the engine is still running. Open and close the throttle repeatedly until the engine stops running on its own. Do this to use up any fuel that still remains in the carburetor. This will help you avoid carburetor problems that can occur when your motorcycle is stored for long periods of time with gasoline left in the carburetor.

MAINTAINING YOUR DIRTBIKE

Keeping your motorcycle in perfect operating condition is absolutely essential to your safety. It is also the best way to protect your investment, get maximum performance, avoid breakdowns, and have more fun. To help keep your motorcycle well maintained, this section includes a maintenance schedule for required servicing and step-by-step instructions on how to perform specific maintenance tasks. In this section you will also find important safety precautions, information on oils, and tips for keeping your Zuumav looking good.

Careful pre-ride inspections and good maintenance are invaluable because your motorcycle is designed to be ridden over rough, off-road terrain. To help you properly care for your motorcycle, this section provides you with a maintenance schedule. The service intervals in this section are based on average riding conditions. More frequent service is needed if you subject your motorcycle to severe use, such as competition, or ride in unusually wet and dusty areas. Frequent checks of the air cleaner are very important to help you avoid engine damage.

Remember, proper maintenance is the responsibility of the owner. Be sure to inspect your motorcycle before each ride and follow the maintenance schedule in this section.

WARNING

Improperly maintaining this motorcycle or failing to correct a problem before you ride can cause a crash in which you can be seriously injured or killed. Always follow the inspection and maintenance recommendations and schedules in this manual.

NOTICE TO PARENTS

As a parent, it is up to you to make sure the motorcycle is properly maintained and kept in safe operating condition. For youngsters, learning how to take care of a motorcycle and perform basic maintenance can be an important part of their riding experience. However, if you allow a youngster to perform or assist in any maintenance task(s), such as filling the fuel tank with gasoline, you need to provide close supervision and make sure the task is performed safely.

WARNING

Failure to properly follow maintenance instructions and precautions can cause you to be seriously hurt or killed. Always follow the procedures and precautions in this manual.

IMPORTANT SAFETY PRECAUTIONS

Make sure the engine is off before you begin any maintenance or repairs. This will help eliminate the following hazards:

1. **Carbon Monoxide Poisoning from Engine Exhaust** – Be sure you have adequate ventilation whenever you operate the engine.
2. **Burns from Hot Motorcycle Parts** – Let the engine and exhaust system cool off before you touch them.
3. **Injury from Moving Parts** – Do not run the engine unless instructed to do so.

Read all instructions before you begin a procedure. Make sure you have all of the tools and skills required. To help prevent the motorcycle from falling over, park it on a firm, level surface, using the side stand or a maintenance stand to provide support. To reduce the chance of a fire or explosion, be careful when working around gasoline. Use only a non-flammable (high flash point) solvent such as kerosene to clean parts. Keep cigarettes, sparks, and flames away from all fuel related parts.

MAINTENANCE SCHEDULE

To keep your motorcycle safe and reliable when you ride, regular inspections and service is required. Below you will find a maintenance schedule that describes when components need to be inspected or serviced. The maintenance schedule lists item that can be performed with basic mechanical skills and hand tools. In addition, the maintenance schedule will list items that involve more extensive procedures and could require special training, tools and/or equipment.

Always perform the pre-ride inspection described on page 16 at each scheduled maintenance interval.

Each item on the maintenance schedule requires some mechanical knowledge. You will find that some items in the table (marked * and **) may require a higher level of mechanical skill and special tools. If you do not feel capable of performing any procedure, please consult your nearest Zuumav dealer.

* Indicates items that require a moderate to high level of mechanical skill. We recommend service by a Zuumav dealer if the owner is not mechanically qualified.

** Indicates items and procedures that require special tools.

Note: Service your motorcycle more frequently when you ride in wet or dusty conditions.

Maintenance Procedures: I = Inspect (clean, adjust or replace if needed), C = Clean, A = Adjust, L = Lubricate, R = Replace

Items	Frequency	Month/Distance					
		1 month/100 miles 2 years	2 months/200 miles 2 years	3 months/300 miles 2 years	4 months/400 miles 2 years	5 months/500 miles 2 years	6 months/600 miles 2 years
* Fuel Line							
* Fuel Filter		I	I	I	I	I	I
* Throttle Operation			I	I	I	I	I
Air Filter		I		I		I	
* Spark Plug			I	I	I	I	I
Engine Oil		I		I		I	
* Engine Air Filter		I	I	I	I	I	I
Drive Chain		inspect & lubricate every 100 miles or 1000 miles					
Drive Chain Sprocket		I	I	I	I	I	I
Master and Slave		I	I	I	I	I	I
Master Sprocket		I	I	I	I	I	I
* Chain Sprocket		I	I	I	I	I	I
* Sprocket		I	I	I	I	I	I
* Suspension		I	I	I	I	I	I
* Shock Absorber		I	I	I	I	I	I
* Fork, Rotor, Suspension		I	I	I	I	I	I
* Wheel Hub Bolt		I	I	I	I	I	I
* Wheel Hub Bolt Tighten		I	I	I	I	I	I
* Oil Filter		I	I	I	I	I	I

Maintenance Procedures: I = Inspect, C = Clean, A = Adjust, L = Lubricate, R = Replace

MAINTENANCE SCHEDULE

Maintenance Required Intervals

[illegible]

MAINTENANCE SCHEDULE

[illegible]

(C) One-time Interview

1.1 Periodic Integrals

Reference Owner Manual

 Maintenance & Inspection, Scheduled Service

BASIC MAINTENANCE PROCEDURES

FUEL (GASOLINE)

Fuel Recommendation – Any unleaded gasoline with an octane rating of **90** or higher.


The engine in your motorcycle has been designed to run on any gasoline with a pump octane rating of **86** or higher. Most service stations will display the octane rating above each pump. Although it is not required, Zuumav recommends use of gasoline with a **90** octane, rating or higher to ensure maximum performance and reliability.

Use of a lower octane gasoline can cause pre-detonation in the engine. When this occurs, you will hear a persistent “pinging” or “spark knock” which, if severe, can cause engine damage. It is however no cause for concern if you hear light pinging while the engine is under hard acceleration, such as climbing up a hill. If pinging occurs under normal load and a steady engine speed, switch brands of gasoline and be sure you are using the proper octane rating. Use of unleaded fuel is recommended because it produces fewer engine deposits and extends the life of the engine and exhaust components.

Never use stale or contaminated gasoline. Never use gasoline that has been mixed with oil. Avoid getting dust, dirt and water into the fuel tank.

INSPECTION & REFUELING PROCEDURE

1. Replace the fuel hose if you feel it is necessary.
Inspect the fuel filter replace if necessary.
2. Twist the fuel tank cap **1** counter clockwise and remove the cap from the tank.
3. Using a funnel, add fuel to the tank until the level reaches about 2 inches from the top of the tank **B**
4. Twist the fuel cap clockwise until it is securely tight.
5. Be sure that you have the breather tube **2** connected to the gas tank cap.



WARNING

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling gasoline. Always stop the engine. Only handle gasoline outdoors. Clean all spills immediately.


BASIC MAINTENANCE PROCEDURES

ENGINE OIL

Using proper oil, and regularly checking, adding and changing oil will help extend the service life of your engine. Even the best oil wears out and becomes thinner. Changing oil helps get rid of dirt and deposits in the engine. Operating the engine with old or dirty oil may and may damage your engine. Running the engine with not enough oil can cause serious damage to your engine.

Engine Oil Recommended – SAE 10w40 / 10w-50 Motor Oil. *

Indicates oil for regular air temperatures. Please see the oil/air temperature chart to help you choose the best oil for your climate.



CAUTION

Your motorcycle does not need oil additives. ONLY use the recommended oil. DO NOT use oil with graphite or molybdenum additives, they may adversely affect the clutch operation. DO NOT use motor oils that display the API circular logo that is labeled "energy conserving", they may affect the lubrication and clutch performance.




Fig. 1

CHECKING & ADDING OIL

1. Stand the motorcycle upright on a horizontal surface. Remove the oil filler cap **A**.
 - A. Engine is cold.
Check the engine oil level with the oil dip stick.
Fig. 1
 1. Engine oil reaches the top notch of the level viewer **B** - **No need to add engine oil.**
 2. Engine oil is in the middle or below of the level viewer **1** - **Need to add engine oil until it reaches the top notch of the level viewer.**
 - B. Engine is at operating temperature.
Check the engine oil level with the oil dip stick.
Fig. 1
 1. Engine oil reaches the top notch of the level viewer. **No need to add engine oil.**
 2. Engine oil is in the middle or below of the level viewer. **Need to add engine oil until it reaches the top notch of the level viewer.**

NOTICE

Improper disposal of drained fluids is harmful to the environment.

NOTICE

If the oil filter and cap are not installed correctly, it will cause serious engine damage.

NOTICE

Dispose of drained oil in an appropriate manner. Most parts stores or auto shops do take used oil.

BASIC MAINTENANCE PROCEDURES

CHANGING OIL & OIL FILTER



1. Park the motorcycle on a level surface.
2. Place a suitable oil container under the engine.
3. Remove the oil drain plug **A** and the seal ring **B**.
4. Let the oil drain out from the engine.

A. Oil Filter Replacement

1. Loosen & remove the oil filter cover **C** be careful not to damage the O-ring. If it is damaged, it needs to be replaced.
2. Pull out the oil filter from the filter housing.
3. Completely drain the oil.
4. Thoroughly clean the parts and sealing surfaces.
5. Insert a new oil filter into the oil filter housing. Make sure it is seated properly.
6. Oil the O-ring of the oil filter housing cover and install it back on to the filter housing.
7. Tighten the filter cover.
8. Stand the motorcycle back up.
9. Remove the oil fill plug with the O-ring from the right side of the engine and fill with new engine oil.
10. Install the oil fill plug with the O-ring.
11. Start the engine and check for any leaks.
12. Check the engine oil level with the dip stick. Don't screw the dip stick back in. Just need to insert the dipstick and pull it back out to check the level.




BASIC MAINTENANCE PROCEDURES

Proper air filter maintenance is extremely important for off-road vehicles. A dirty, water-soaked, worn-out air filter will allow dirt, dust, mud or other impurities to pass into the engine. If you are riding in wet and/or muddy areas, you should service the air filter more often. Always replace the air filter with a genuine Zuumav filter specifically designed for your model or a filter of equal quality. Failure to maintain the filter can/may cause engine wear or damage, expensive repairs, low engine power, low fuel mileage, carbon build up on valves and foul the spark plug.

CHANGING / CLEANING AIR FILTER



1. Remove the 2 screws **A**



1. Pull out the air filter cover by pulling in areas **B** sideways.
2. Remove the air filter cover by sliding it toward the front of the motorcycle.



1. Detach air filter holder **A** at bottom and move it to one side.
2. Remove the air filter and filter support.

NOTICE

Improper or lack of proper air filter maintenance can/will cause poor performance.

BASIC MAINTENANCE PROCEDURES

CHANGING / CLEANING AIR FILTER



1. Wash the air filter element in a clean non-flammable cleaning solvent.
2. Then, wash in hot, soapy water, rinse well, and allow to air dry thoroughly. The air filter element is made in two parts: the inner and outer, which of course cannot be separated.
3. Clean the inside of the air filter housing.



1. Allow the air filter element to dry thoroughly.
2. After drying, apply 1.5 oz. (45mL) of clean new Foam Air Filter Oil from the inside of the air filter element.
3. Place the air filter element into a plastic bag 5 and spread the oil evenly by hand.




1. Assemble the air filter element and holder together.
2. Apply White Lithium Grease to the air filter housing contact area of the air filter element A.
3. Install the air filter assembly into the air cleaner housing.
4. Carefully position the sealing flange of the air filter element to prevent dirt from getting in.

NOTICE

Improper installation of the air cleaner assembly may/will allow dirt and dust to get inside the engine and cause rapid wear of the piston rings and cylinder

BASIC MAINTENANCE PROCEDURES


CHANGING / CLEANING AIR FILTER



1. Insert both parts together into the air filter housing.
2. Make sure the position is correct.
3. Fasten the air filter using the filter holder **A**
4. Clip the holder in the correct position **B**

NOTICE


Improper installation of the air cleaner assembly may/will allow dirt and dust to get inside the engine and cause rapid wear of the piston rings and cylinder



1. Insert the air filter cover into area **A** and clip it into the front area.
2. Mount and tighten the screws **B**
3. Now the air filter cover is secure.

BASIC MAINTENANCE PROCEDURES

THROTTLE ADJUSTMENT




- A.** Throttle free-play should be 3 – 5 mm (0.10-0.20 in.)
B. If your throttle has more free-play than specified above, adjustments need to be made. Follow the steps below.
C. Minor adjustments are generally made with the upper adjuster.
1. Pull back the rubber dust cover **A**
 2. Loosen the lock nut **B**
 3. Turn the adjuster **C** in the **+** direction will decrease the free-play. Turn the adjuster in the **-** direction will increase free-play.
 4. Operate the throttle to ensure that it is functioning smoothly, and when released, it returns completely very quickly from full open throttle to fully closed in all steering positions.
 5. Inspect the condition of the throttle cable from the throttle down to the carburetor. If the cable is nicked or chafed, it must be replaced.
 6. Lubricate the cable with a commercially available cable lubricant to prevent premature rust and/or corrosion.
 7. Check the cable for tension or stress in all steering positions.

BASIC MAINTENANCE PROCEDURES

In order, to ensure the best performance and durability from the clutch, always be sure you have proper clutch free-play. Free-play is needed to ensure that the clutch has room for wear. A clutch with no free-play will begin to slip as the discs wear down. Failure to fix a slipping clutch can cause clutch damage. To check the free-play, simply pull on the clutch lever. The lever should move very easily within the free-play range before you feel the clutch begin to engage. If too much or too little free-play exists, adjustments are needed.


CLUTCH LEVER & CABLE ADJUSTMENT



A. Clutch Lever Adjustment (If applicable)

The distance between the grip and the tip of the clutch lever can be adjusted to suite the size of your hand.

1. Loosen the lock nut **A**
2. To make the position of the clutch lever farther away from the tip of the grip, turn the adjuster **B** screw in a clockwise rotation.
3. To make the position of the clutch lever closer to the tip of the grip, turn the adjuster screw in a counter-clockwise rotation.
4. Once you are comfortable with the position of the lever, tighten the lock nut securely.
5. **FREE-PLAY: 10mm-20mm (0.4-0.8 in.)**



B. Cable End Adjustment (free-play)

Minor adjustments are generally made with the clutch cable end adjuster.

1. Turning the cable end adjuster **A** in the **+** direction will increase the free-play
 2. Turning the cable end adjuster **B** in the **-** direction will decrease the free-play.
- If the adjuster is threaded out near its limit or the correct free-play cannot be reached, turn the adjuster all the way in and back in out one full turn and make the adjustment with the integral cable adjuster on the engine.



C. Integral Cable Adjustment

The integral cable adjuster is used if the cable end adjuster is threaded out near its limit, or the correct free-play cannot be obtained.

1. Pull back the black rubber cover **A**
2. Loosen the lock nut **B**
3. Turn the adjuster nut **C** to obtain the specified free-play.
4. Tighten the lock nut. Check the free-play

Make sure the gear is in Neutral. Start the engine and pull the clutch lever in and shift into gear. Make sure the engine does not stall and the motorcycle does not creep. Gradually release the clutch lever and open the throttle. Your motorcycle should now move smoothly and accelerate gradually.

If you can't get the proper adjustment, or the clutch does not work properly, the cable might be kinked or worn out or the clutch friction discs may be worn out. Take to your local ZUUMAV dealer for inspection.

BASIC MAINTENANCE PROCEDURES


The recommended standard spark plug will work very well in most riding condition. However, if you plan on riding for extended periods of time at high speed or high engine rpm in hot climates, or plan extended riding in cold climates, a different plug may be recommended.

Use only the recommended type of spark plug.

SPARK PLUG

A fouled (dirty) spark plug can cause your motorcycle to run poorly and lose performance. Follow the steps below to inspect, clean and/or replace the spark plug if needed.

1. Clean any dust or dirt from around the spark plug base area thoroughly to prevent dirt from entering the cylinder.
2. Disconnect the spark plug cap.
3. Remove the spark plug.
4. Using the photos below for a reference, examine the spark plug to determine its cleanliness. If the plug has a normal color, GO TO STEP 6. If the spark plug is fouled (dirty), GO TO STEP 5.
5. Using a moderate grit sandpaper (220-400), sand between the center electrode and the side electrode until all carbon and oil deposits are removed. We recommend that you use a spark plug cleaner or a new spark plug if the old spark plug is very dirty.
6. Check the electrodes for wear or deposits, the sealing ring for damage and the insulator for cracks or chips. The center electrode should be nicely rounded or have square edges (depending on the type of spark plug you are using) the side electrode should not be eroded at all. Replace the spark plug if you detect either.
7. Check the spark plug gap using a wire type feeler gauge. If the gap is not as specified, replace the spark plug with a new one.
8. Be sure all dirt has been cleaned from the threads if you are using the old spark plug. Install the spark plug by hand first. This will prevent stripping and/or cross threading the threads. Use the appropriate socket or wrench to securely tighten the spark plug. Do not over or under tighten the spark plug.
9. Tightening the spark plug:
 - A. If using the old spark plug:
 1. First, tighten the plug $\frac{1}{8}$ turn after it seats.
 - B. If using a new spark plug:
 1. First, tighten the plug $\frac{1}{2}$ turn after it seats.
 2. Then loosen the spark plug.
 3. Next, tighten the plug again:
 $\frac{1}{8}$ turn after it seats.



When you inspect the spark plug, generally it will fit into one of the four categories shown above. A normal/clean spark plug will have a light brown center and displays no wear around the electrodes. A spark plug with a bright white center indicates a lean condition in the engine. If your plug looks like this, have your motorcycle serviced by your Zuumav dealer immediately. A carbon fouled plug will be completely black with no gloss. An oil fouled plug will appear a dark shiny brown or shiny black as shown above. An oil fouled plug is caused when the engine oil seeps by the piston ring and is burned with the fuel. Oil fouled plugs are not uncommon, however, if your motorcycle is consistently oil fouling spark plugs, have it serviced by your local Zuumav dealer immediately.

BASIC MAINTENANCE PROCEDURES


SPARK PLUG Cont.

! NOTICE
Using a spark plug with an improper heat range or incorrect reach, can cause engine damage. Using a non-resistor spark plug may cause ignition problems.

! NOTICE
An improperly tightened spark plug can damage the engine. If a plug is too loose, a piston may be damaged. If a plug is too tight, the threads may be damaged.

BASIC MAINTENANCE PROCEDURES

Both the front and rear brakes are the hydraulic oil disc type. As the brake pads wear out, the brake fluid level will drop. A leak in the system will also cause the level to drop. Frequently inspect the system to ensure there are no fluid leaks. Periodically inspect the brake fluid level and the brake pads for wear. If the braking response of the front brake lever or rear pedal feels unusual, check the brake pads. If the brake pads are not worn beyond the recommended limits, there is probably air in the brake system. Refer to your local ZUUMAV dealer to have the air bled from the system.



BRAKEING SYSTEM (Front Brake Lever)

1. Loosen the lock nut (A).
2. To position the brake lever away from the grip, turn the adjuster (B) clockwise.
3. To position the brake lever closer to the grip, turn the adjuster counter-clockwise.
4. Once you determine the lever is in a good position, while holding the adjuster, tighten the lock nut.
5. Apply a little bit of silicone grease or marine grease to the contacting areas of the adjuster.



BRAKEING SYSTEM (Rear Brake Pedal)

1. Loosen the lock nut (A) and turn the push rod (B) in the + direction to raise the rear brake pedal (C) or in the - direction to lower it.
2. Tighten the adjuster lock nut at the desired pedal height.
3. The brake pedal height should be approximately level with the foot rest.



BRAKEING SYSTEM (Front Fluid Level Check)

1. With the motorcycle in the upright position, check the brake fluid level. It should be above the indicator mark (A) on the master cylinder. If the level is below the mark, check the brake pads for wear. Worn out pads should be replaced. If the brake pads are not worn out, check your brake system for leaks.



BRAKEING SYSTEM (Rear Fluid Level Check)

1. With the motorcycle in the upright position, check the brake fluid level. It should be above the indicator mark (A) on the master cylinder. If the level is below the mark, check the brake pads for wear. Worn out pads should be replaced. If the brake pads are not worn out, check your brake system for leaks.

BASIC MAINTENANCE PROCEDURES

Hydraulic brakes require brake fluid for its operation. Both front and rear brakes have a brake fluid reservoir built into the master cylinders. Follow the procedures below to check and fill the cylinders with the specified brake fluid.


BRAKEING SYSTEM Cont.

RECOMMENDED BRAKE FLUID ONLY – DOT 4

NOTICE

USE ONLY DOT 4 BRAKE FLUID.

ADDING BRAKE FLUID (Front)



1. Clean all dirt and dust from the master cylinder cap **A** before opening.
2. Remove the cap screws **B** with a phillips head screwdriver.
3. Remove the cap. Be careful not to damage the diaphragm gasket that is seated under the cap.
4. Add the required amount in to the cylinder (DO NOT OVERFILL) Always use new fluid from a sealed container.
5. Replace the diaphragm and cap and tighten the screws securely.
6. Slowly squeeze the brake lever to be sure the brakes are working properly.
7. Check the brake hose and brake caliper for leaks.

ADDING BRAKE FLUID (Rear)



8. Clean all dirt and dust from the master cylinder cap **A** before opening.
9. Remove the cap screws **B** with a phillips head screwdriver.
10. Remove the cap. Be careful not to damage the diaphragm gasket that is seated under the cap.
11. Add the required amount in to the cylinder (DO NOT OVERFILL) Always use new fluid from a sealed container.
12. Replace the diaphragm and cap and tighten the screws securely.
13. Slowly squeeze the brake lever to be sure the brakes are working properly.
14. Check the brake hose and brake caliper for leaks.

If you are unsure how to re-assemble a part, please contact your ZUUMAV dealer for servicing information and/or servicing.

NOTICE

USE ONLY DOT 4 BRAKE FLUID.


NOTICE

Be very careful not to spill brake fluid on painted surfaces or it will damage the paint. It will also be harmful to some rubber parts. Be careful when you remove the master cylinder cap, make sure the motorcycle is in an upright position.

BASIC MAINTENANCE PROCEDURES

Hydraulic disc brake systems use a brake caliper to squeeze the rotors (brake disc) which causes the motorcycle to stop. Inside the brake caliper are brake pads. The brake pads are the part of the brake system that makes contact, with the brake rotor. The pads must be checked in accordance with the maintenance schedule for the brake system as described on page 24. Follow the procedure below to check the brake pad wear. Brake pad wear depends on the severity of use and track conditions. (Usually, the pads will wear out faster with wet and dirty track conditions.)

Brake Pads



1. Inspect the brake pads **A** at each maintenance interval through the wheel to determine the brake pad wear. (More frequently if you do a lot of riding).
2. If either of the pads are worn down to a thickness of 1 mm, then both pads **MUST** be replaced.
3. If one side has worn down more extensive than the other, consult your ZUUMAV dealer for a possible bad brake caliper.
4. If you are unsure how to replace the brake pads, please contact your nearest ZUUMAV dealer for assistance, or schedule your motorcycle for servicing.

BLEEDING THE BRAKE SYSTEM

Because the brake system utilizes fluid, any air bubbles inside the brake system will cause you to lose braking efficiency. Air generally enters the brake system when the motorcycle sits unused for long periods of time. Air will also enter the system if you have a leaking brake hose, brake caliper or master cylinder. A brake system with air will cause the brake lever and pedal to feel soft and spongy. Use the procedure below to bleed air from both the front and rear brake system.

ADDING BRAKE FLUID (Front)



NOTICE

USE ONLY DOT 4 BRAKE FLUID.

1. Clean all dust and dirt from the bleeder screw and remove the rubber screw cap.
2. Slowly pump the brake lever or pedal slowly and firmly 4 – 6 times and then hold it (keep it in the pressed position).
3. Using an 8mm bleeder wrench, loosen **⊖** the bleeder screw **A** located on the brake caliper. You will see brake fluid, and possibly some air will exit out of the bleeder screw.
4. Once the fluid has stopped, tighten **⊕** the bleeder screw and then slowly release the lever or pedal.
5. Repeat steps 2 – 4 until all air bubbles have stopped flowing from the bleeder screw and only fluid is coming out. The lever/pedal should feel hard and firm when you are complete.
6. If the fluid level in the master cylinder is going down, please remember to replenish the fluid until the air bleeding is done.

BASIC MAINTENANCE PROCEDURES

Loose, worn or damaged suspension components may affect the stability and handling of your motorcycle. If any of the suspension components seem to be worn or damaged, see your Zuumav dealer for service and/or inspection. Your Zuumav dealer is the most qualified to determine, whether or not replacement parts or service is required. Your motorcycle is new. Break it in for about 2 hours with the original settings before attempting adjustments.

SUSPENSION INSPECTION (Front)



1. Check the fork operation by pulling in the front brake lever and holding it to lock the front wheel.
2. Make sure the plastic fork protectors and dust seals are clean and not packed with dirt or mud.
3. Next, pump down on the handle bars several times. The suspension should feel clean and smooth.
4. Check the lower end of the forks (near the wheel) for oil leaks. Damaged or leaking fork seals should be replaced before your next ride.
5. Inspect the upper ② and lower ③ triple clamps for tightness.
6. Be sure all the triple clamp bolts ① are tight.
7. Examine the metal for any cracks, wear or other damage.
8. Be sure there is no free-play in the steering head ④

SUSPENSION INSPECTION (Rear)



1. Move the motorcycle by bouncing it up and down to check for smooth suspension action.
2. Check for a broken or damaged spring.
3. Check the shock absorber for a bent center shaft or any oil leaks.
4. Check the nuts and bolts of the shock for tightness.
5. Check the spring adjuster(s) ring for tightness.
6. Check the swing arm bolt for tightness.
7. Check the bottom linkage nuts and bolts for tightness.
8. Push the rear wheel sideways to check for any worn or loose swingarm bearings ①. If there is, have the bearings replaced by your Zuumav dealer.

NOTICE

DO NOT TRY TO REPAIR THE SHOCK.
IF REPAIR IS NECESSARY, TAKE THE
MOTORCYCLE TO A ZUUMAV DEALER.

BASIC MAINTENANCE PROCEDURES

SUSPENSION DAMPING (Front)



Compression Adjustment (if applicable)

This adjustment effects how quickly the front forks compress. The compression adjuster has 18 click positions. Turning the compression adjuster screw one click changes how the fork compression responds. To adjust the forks to the standard position, please follow the instructions as follows:

1. Turn the adjuster screw ① fully clockwise until it will not turn any longer (lightly seated). This is the full hard position.
2. Turn the adjuster counter-clockwise 6-7 clicks. This is the standard position.
3. Make sure both fork adjustments are set to the same position.



Rebound Adjustment (if applicable)

This adjustment effects how quickly the front forks rebound back from a compressed position. The rebound adjuster has 16-18 clicks. Turning the rebound adjuster screw one click changes how quickly the forks extend. To adjust the forks to the standard position, please follow the instructions as follows:

1. Turn the adjuster screw ① fully clockwise (+) until it will not turn any longer (lightly seated). This is the full hard position.
2. Turn the adjuster counter-clockwise (-) 10-11 clicks. This is the standard position.
3. Make sure both fork adjustments are set to the same position.

NOTICE

DO NOT TRY TO REPAIR THE FORKS.
IF REPAIR IS NECESSARY, TAKE THE
MOTORCYCLE TO A ZUUMAV DEALER.

BASIC MAINTENANCE PROCEDURES

SUSPENSION Cont.



SUSPENSION AIR PRESSURE (Front)

Air is usually an unstable gas which does build up pressure as its worked (usually in the forks). Air pressure acts like a progressive spring which effects the travel range of the forks. Meaning, the fork action on your motorcycle will get stiffer during a race or long hours on the test track. You need to relieve the accumulated pressure in the forks by using the pressure relief screws in the following order:

1. Place the motorcycle on a motorcycle stand.
2. Make sure the front wheel is off the ground, it must be fully extended.
DO NOT remove the relief screw with the front wheel on the ground.
3. Slowly remove the relief screw **A** by turning it counter-clockwise.
4. Do this to both left and right fork.
5. Remove the relief screw and check the O-rings are in good condition. If they are not, they need to be replaced before your next ride.
6. Once the pressure has been released, install and tighten the relief screws by turning them clockwise. Do not over tighten them, just enough to be snug. Overtightening will damage the O-rings.

BASIC MAINTENANCE PROCEDURES


The rear suspension of your motorcycle has 2 different adjustment points. It can be adjusted for the rider's weight and riding conditions by changing the spring pre-load, rebound and compression damping points. It comes from the factory set to the softest setting. If you wish to make the rear suspension harder, follow the procedures below. Adjusting the rear shock is not hard, but like the front forks, changes should be made one at a time to gain an accurate understanding of how they affect the bike.

Once you are familiar with the settings on your suspension, you can quickly and easily adjust them to suit different terrain. For example, you know the setting position for when you ride in the sand dunes. But when you are riding on your local track you know to tune them to a different setting.

The rear shock absorber has a damper unit that contains high pressure nitrogen gas. Do not attempt to disassemble, service or dispose of it. Puncture or exposure to flame may also result in an explosion, causing serious injury or even death. Service or disposal should only be done by your dealer or a qualified mechanic that is equipped with the proper tools and safety equipment.

If your H7L motorcycle is new, put about 2 hours of part throttle break in time on it to ensure that the shock absorber has worked in.

SPRING PRE-LOAD




The spring pre-load should be adjusted when the engine is cold because it will be necessary to remove the muffler(s). A second spanner will be needed for turning the shock spring lock nut and adjusting the nut in order to adjust the spring pre-load.

1. Recommended to place your H7L on a stand or equivalent support with the rear wheel off the ground.
2. Remove the mufflers.
3. Loosen the clamp on the air filter duct connecting the carburetor.
4. Remove the battery terminal connectors.
5. Remove the sub-frame with the air filter housing on one piece.
6. Check that the spring pre-load is adjusted to the standard length.
7. Adjust as necessary by loosening the shock spring lock nut **A** and turning the adjusting nut **B**.
8. One complete turn of the adjuster nut changes the spring length by approximately 1.5 -2 mm.
9. After the adjustment has been done, hold the adjuster nut and tighten the spring lock nut.
10. Make sure the lock nut is tight before you assemble the remaining parts.

BASIC MAINTENANCE PROCEDURES

SUSPENSION Cont.



SPRING PRE-LOAD Cont.

Increase Spring Pre-Load

1. Loosen the lock nut on the spring with the spanners **C** and turn the adjuster nut clockwise to shorten the spring length **D**.
2. One complete turn of the adjuster nut changes the spring length by approximately 1.5 -2 mm.
3. After the adjustment has been done, hold the adjuster nut and tighten the spring lock nut.
4. Make sure the lock nut is tight before you assemble the remaining parts.

Decrease Spring Pre-Load

1. Loosen the lock nut on the spring with the spanners **C** and turn the adjuster nut counter-clockwise to increase the length of the spring **D**.
2. One complete turn of the adjuster nut changes the spring length by approximately 1.5 -2 mm.
3. After the adjustment has been done, hold the adjuster nut and tighten the spring lock nut.
4. Make sure the lock nut is tight before you assemble the remaining parts.

SHOCK ABSORBER DAMPING




Compression Damping (if applicable)

- A.** The high-speed compression damping **A** is effective when damping adjustment is desired for high speed operation.
- B.** The low-speed compression damping **A** is effective when damping adjustment is desired for low speed operation.
1. Both the high and low speed compression damping can be increased or decreased by turning the center screw adjuster clockwise or counter-clockwise.
 2. You can adjust the adjuster by turning it 1/12th turn increments (clicks).

BASIC MAINTENANCE PROCEDURES

SUSPENSION Cont.

7. Next, you will find the rebound adjuster at the bottom of the shock absorber, under the swing-arm. This works much the same as the rebound screw on the front forks. It controls how quickly or slowly the shock returns to its extended position after being compressed.
8. Try turning it clockwise to allow the rear wheel to stay in contact with the ground over larger rolling terrain.
9. If you turn the screw counter-clockwise, this will give you a better ride over rough bumps that are close together by allowing the shock to rebound faster and “hug” the flow of the terrain.



SHOCK ABSORBER DAMPING

1. The rebound damping adjuster **A** is located at the lower end of the shock absorber.
2. It has 12-14 adjustment positions. Turning the adjuster screw one full turn advances the adjuster by 4 positions (clicks).
3. Rebound damping can be increased by turning the adjuster clockwise **+** or counter-clockwise **-**.
4. To adjust to the standard position, turn the adjuster clockwise until it will not longer turn (DO NOT FORCE). This is the fully hard setting.
5. Turn the adjuster counter-clockwise 9-12 clicks.

NOTICE

DO NOT TRY TO REPAIR THE SHOCK.
IF REPAIR IS NECESSARY, TAKE THE
MOTORCYCLE TO A DEALER.

BASIC MAINTENANCE PROCEDURES

Maintenance of spoke tension and wheel trueness (roundness) is critical to safe motorcycle operation. During the first 100miles of riding, spokes will loosen faster due to the initial seating of the parts. Excessively loose spokes will cause the motorcycle to become unstable at high speed and could cause you to lose control. Loose spokes can also cause rim and spoke damage (not covered in the warranty). It is not necessary to remove the wheels for regular maintenance. However, information on wheel removal is available from Zuumav.



WHEEL INSPECTION FRONT & REAR

- 1. Inspect the wheel rims **A** and spokes **B** for damage or looseness. Feel the spokes with your fingers to make sure none are loose.
- 2. Tighten any loose spokes with a small adjustable wrench or spoke wrench from the spoke nut **C**.
- 3. Elevate each wheel off the ground, one at a time, and spin the wheel slowly. Look for a wobble in the wheel. If a wobble is evident, the wheel is not "true". See your local Zuumav dealer or local motorcycle shop for inspection of the wheels.

TIRE AIR PRESSURE

Properly inflated tires will provide you with the best combination of handling, tread life, and riding comfort. Underinflated tires will wear unevenly and adversely affect handling. Underinflated tires are also more likely to fail from being overheated and can cause wheel damage on rocky terrain. Overinflated tires will cause the motorcycle to ride harshly, are prone to failure from surface hazards and wear unevenly.

Make sure the valve stem caps are secure, if needed, install a new cap. Always check air pressure when your tires are cold. If you check the air pressure when the tires are warm, you will get higher readings. If you let air out of warm tires to match the recommended cold tire pressure, the tires will be under inflated. The correct cold tire pressures are listed below. If you replace the tire, follow the tire Pressure marked on the sidewall of the tire.

WARNING

USING TIRES THAT ARE EXCESSIVELY WORN OR IMPROPERLY INFLATED CAN CAUSE A CRASH IN WHICH YOU CAN BE SERIOUSLY INJURED OR KILLED. FOLLOW ALL INSTRUCTIONS IN THIS OWNER'S MANUAL REGARDING TIRE INFLATION AND MAINTENANCE.

TIRE PRESSURE	
Front Tire	20 Psi (138 kPa)
Rear Tire	20 Psi (138 kPa)

BASIC MAINTENANCE PROCEDURES

A flat tire or tire blowout can be very inconvenient and can even cause you to have an accident. Take the time to inspect your tires and wheels before you ride. For more information about handling a flat tire, refer to the section of this manual titled, [Resolving the Unexpected](#).

- Inspect the tire carefully for bumps or bulges in the sidewall of the tire and inside of the treads. replace any tires that have bumps or bulges in them.
- Look closely for cuts, slits or cracks in the tires. Replace any tire if you can see a fabric or cord showing through.
- Check for rocks or other objects embedded in the tires or tread. Remove any foreign objects. Be sure there are no screws or nails in the tires.
- Measure the tread depth of the tires. Replace all tires before the read depth gets below 0.12in (3mm) or anytime you notice a reduction in your traction.
- Check the position of both valve stems. A tilted valve stem indicates that the tube is slipping inside of the tire or the tire is slipping on the rim. See your Zuumav dealer for assistance.

TIRE & TUBE REPLACEMENT

If a tube has been punctured or damaged, it should be replaced immediately. You may repair the tube using a tube patch kit. However, a repaired tube may not have the same reliability as a new one and could fail while riding. For more information on a temporary repair, see the section titled [Resolving the Unexpected](#).

Always use replacement tubes that are the same size as the original. We recommend that you have tubes changed at your local Zuumav dealer or your local motorcycle shop. Replacing a tube requires removal and installation of the wheel. Anytime you have a tube replaced, perform the tire inspection listed at the top of this page. The tires that came on your motorcycle were designed to provide a good combination of handling, braking, durability and comfort across a broad range of riding conditions.

- Use a replacement tire equivalent in size and type to the original tire.
- Replace the tube anytime you replace a tire. Old tubes are usually stretched and, if installed in a new tire, could fail.
- Have the wheel balanced after a new tire has been installed.
- We recommend that tires be replaced by your Zuumav dealer or a local motorcycle shop.

TIRE PRESSURE

Front Tire	20 Psi (138 kPa)
Rear Tire	20 Psi (138 kPa)
Type	Bias Ply, Tube Type

⚠ WARNING

INSTALLING IMPROPER TIRES ON YOUR MOTORCYCLE CAN AFFECT HANDLING AND STABILITY. WHICH, IF SEVERE, CAN CAUSE A CRASH IN WHICH YOU CAN BE SERIOUSLY HURT OR KILLED. ALWAYS USE THE SIZE AND TYPE OF TIRES RECOMMENDED IN THIS OWNER'S MANUAL.

BASIC MAINTENANCE PROCEDURES

The service life of your drive chain will depend on several factors including proper lubrication, adjustment, and riding style. If you are an experienced rider and tend to ride in a more intense manner, or you ride in muddy/dusty areas, you will need to check the drive chain more frequently. Poor maintenance will cause pre-mature wear and/or damage to the drive chain and sprockets.

Before you service your drive chain, be sure you are parked on a level surface and you turn the engine OFF. Be sure the transmission is in neutral. It is not necessary to remove or replace the chain to perform recommended maintenance service.

CHAIN INSPECTION



1. Check the slack in the lower drive chain midway between the sprockets **A**. Push upward on the chain with your finger. The vertical movement should measure between 8-10mm
2. Repeat step 1 along several points of the drive chain. The slack should remain constant throughout. If it is not, some links may be kinked and binding. Lubricating the chain will often stop this from happening.
3. Inspect the drive chain for the following: damaged rollers, loose pins, dry or rusted links, kinked or binding links and excessive wear. Replace the chain, loose pins or kinks that cannot be freed. Lubricate the drive chain if it appears dry or shows signs of rust. Lubricate any kinked or binding links and work them free.
4. You should replace the drive chain once the rear axle is moved as far back as possible and slack remains. This indicates that the chain is worn beyond its service limit.
5. Inspect the front and rear sprockets for excessive wear and/or damage. Refer to the illustration at the top of page 50. If needed, replace any worn or damaged sprocket(s). See your local Zuumav dealer for assistance.

NOTICE



EXCESSIVE DRIVE CHAIN SLACK MAY ALLOW THE DRIVE CHAIN TO DAMAGE THE ENGINE CASE.

NOTICE

ALWAYS USE HIGH QUALITY LUBRICANT FOR THE DRIVE CHAIN

BASIC MAINTENANCE PROCEDURES

Use the diagram below to determine if the sprocket(s) need to be replaced. Never use a new chain with a damaged or worn sprocket.



DRIVE CHAIN ROLLERS

1. Check the bottom **A** chain roller for wear and/or damage. Measure the diameter of the drive chain roller and replace it if it falls below the limits indicated below:
Roller: 28 mm (New Roller: 35 mm)
2. Check the roller bearings to make sure they are not damaged, and they roll easily. If you feel any resistance while turning the bearing between your fingers, they must be replaced.
3. During installation of new rollers, clean the threads of the roller bolt and apply Loc-Tite 243 agent to the threads.
4. Tighten the roller bolts and nut.
5. Make sure they are tight and will not vibrate off.

BASIC MAINTENANCE PROCEDURES




Fig. 1




Fig. 2

DRIVE CHAIN SLIDERS

1. Check the swing-arm chain slider **A** for wear and/or damage. Fig. 1
2. Replace the slider if falls below the limits indicated below:
Top Section: 5 mm
Bottom Section: 3 mm
3. Check the rear sprocket chain guide slider **B** for wear and/or damage. Fig. 2
4. Replace the slider if it's worn down to the bottom wear limit **C**

NOTICE

THE SLIDERS MUST BE REPLACED IF WORN DOWN TOO FAR.

BASIC MAINTENANCE PROCEDURES

Follow the procedure below to make adjustments to the drive chain slack. Be sure that you are parked on a level surface and the engine is turned OFF.




Fig. 1



Fig. 2



DRIVE CHAIN ADJUSTMENT

1. Loosen the rear axle nut **A**.
2. Loosen the adjuster lock nuts **B** on both the left and right side of the swing-arm.
3. Turn the adjusting bolts **C** counter-clockwise to decrease the slack or clockwise to increase the slack.
4. Align the marks **1** in Fig. 2 of the adjusting plate **D** blocks with the same reference marks **E** on both sides of the swing-arm.
5. Tighten the axle nut **A** to the torque specs. Below.
65 lbs.ft – 88 N.m
6. Recheck the chain slack and adjust it if necessary.
7. If you chain slack is correct, turn the adjuster bolts counterclockwise until they touch the axle plate blocks lightly.
8. Tighten the adjuster lock nuts while at the same time holding the adjuster bolts with a wrench.

CHAIN LUBRICATION

Commercially prepared chain lubricants may be purchased at many motorcycle shops and should be used instead of motor oil. Chain lube or gear oil (80w or 90w) is recommended. Saturate each joint so that the lubricant penetrates the space between each surface of the link plates and rollers.

BASIC MAINTENANCE PROCEDURES

If you have been riding in extremely muddy or dusty conditions, the drive chain should be removed and cleaned before you apply lubricant. Follow the procedure below to remove and clean or replace the drive chain with a new one.

CHAIN REMOVAL, CLEANING & REPLACEMENT



1. Remove the chain master link retaining clip with needle nose pliers. Do not bend or twist the clip. Remove the master link and remove the drive chain.
2. Clean the drive chain with a non-flammable solvent such as kerosene – NOT gasoline – and allow it to dry.
3. Inspect the drive chain for possible wear or damage. Replace the drive chain if it has any damaged rollers, loose fitting links or otherwise appears unserviceable.
4. Inspect the sprockets for wear or damage. Zuumav recommends that you replace the sprockets when you install a new drive chain.
5. Pass the chain over the sprockets and join the ends of the chain with the master link. For ease of assembly, hold the chain ends against adjacent rear sprocket teeth while inserting the master link. Install the master link retaining clip so that the closed end of the clip will face the direction of the forward wheel rotation.
6. Don't forget to lubricate the chain thoroughly.

The master link is the most critical element of drive chain security. Master links are reusable, if they are in excellent condition. We recommend installing a new master link when you install a new drive chain. You may find it easier to install a new chain by connecting it to the old chain using a master link and pulling the old chain to position the new chain on the sprockets.

APPEARANCE CARE

To clean the motorcycle, you can use any of the following: water, mild neutral detergents, mild spray and wipe cleaner, mild spray and rinse cleaner/degreaser. Avoid products that contain harsh detergents or chemical solvents that can damage the metal, paint and plastic on your motorcycle.

We recommend that you use a garden hose to wash your motorcycle. High pressure washers (like coin operated car washers) can damage certain parts of the motorcycle. If you must use a high-pressure washer, avoid spraying the following areas: Wheel hubs, muffler outlet, underneath the seat, engine stop switch, underneath the gas tank, drive chain and carburetor.

NOTICE

HIGH PRESSURE WATER OR AIR CAN DAMAGE CERTAIN PARTS OF THE MOTORCYCLE. NEVER WASH THE MOTORCYCLE WHILE THE ENGINE IS RUNNING. ALWAYS LUBRICATE THE DRIVE CHAIN AFTER YOU ARE FINISHED WASHING AND THE MOTORCYCLE IS DRY.

TROUBLESHOOTING

ENGINE DOES NOT START or IS HARD TO START

1. **Examine the Spark Plug** – Remove the spark plug and inspect

Is the spark plug in good condition?

NO - Flooded engine and/or carburetor

- Choke valve is closed
- Throttle is stuck in the open position
- Dirty or clogged air filter
- Excessively worn piston rings (See your Zuumav dealer)

YES - Go to STEP 3.



NOTICE

DO NOT TOUCH THE SPARK PLUG OR PLUG CAP WHILE TRYING TO START THE ENGINE. YOU WILL RECEIVE AN ELECTRICAL SHOCK WHICH COULD RESULT IN SERIOUS INJURY OR DEATH.

2. **Spark Plug** – Test for ignition spark by removing the spark plug and using a spark tester found at your local auto shop or by inserting it into the spark plug cap. Place the open end of the spark plug on a metal part of the engine and kick start the engine or use the electric start. You should see a nice blue spark on the end of the spark plug. A faint spark will not start the engine.

Is there a good spark?

NO - Fouled or faulty spark plug

- Broken or shorted spark plug wire or spark plug cap.
- Broken or shorted ignition coil
- Faulty ignition CDI box
- Faulty or shorted magneto assembly
- Broken or shorted engine stop switch
- Loose or corroded wires and/or connectors (always clean bad electrical connections)

YES - Go to STEP 4

3. **Cylinder Compression Test** – Perform a simple compression test by kick starting the engine slowly.

Be sure you have the spark plug installed. While pushing down on the kick starter slowly, you should feel a very hard firmness that will abruptly soften as the kick start lever moves further down. No hard firmness in the kick start lever means you have poor compression.

Is the compression normal?

NO - Valve stuck open/seized or improper valve timing (see your local Zuumav dealer)

- Worn cylinder wall and/or piston rings (see your local Zuumav dealer)
- Leaking or damaged cylinder head gasket (see your local Zuumav dealer)

YES - Go To Step 5

TROUBLESHOOTING

5. **Engine Start Condition** – Start the engine by using the normal starting procedure:
Does the engine start but then quickly stops afterward?

- YES** - Improper choke operation
- Dirty or improperly adjusted carburetor (Contact your local dealer)
 - Intake manifold/pipe leak
 - Improper ignition timing (see your local dealer)
 - Dirty or contaminated gasoline.

TROUBLESHOOTING

ENGINE LACKS POWER

1. **Examine the Drive Train** – Raise the wheel off the ground and spin by hand.
Does the wheel spin freely?
NO - Brake dragging, improperly mounted brake pads
- Worn or damaged wheel bearings
- Bent Axle
YES - Go to STEP 2
2. **Check the Tire Pressure** – use a tire pressure gauge to check the tire pressure of each tire.
Is the tire pressure correct?
NO - Punctured tire and/or inner tube
- Faulty tire valve
YES - Go to STEP 3
3. **Clutch Inspection** – Accelerate rapidly through first and second gears.
Does the engine RPM/speed decrease properly when you shift from first gear to second gear?
NO - Slipping clutch, adjustment needed
- Worn out clutch discs and/or plates
- Weak clutch springs
- Contaminating additive in the engine oil
YES - Go to STEP 4
4. **Engine Performance Inspection** – Accelerate lightly.
Does the engine speed increase?
NO - Clogged air filter
- Restricted or clogged fuel line and/or fuel filter
- Clogged muffler/spark arrester
- Choke valve is closed
- Clogged fuel tank breather hose
YES - Go to STEP 5
5. **Spark Plug Inspection** – Remove the spark plug and inspect
Is the spark plug in good working condition?
NO - Spark plug is not serviced frequently enough
- Incorrect spark plug heat range
- Incorrect spark plug gap
YES - Go to STEP 6

TROUBLESHOOTING

6. **Engine Oil Inspection** – Check the oil level and the condition of the oil.

Is the engine oil level correct and in clean condition?

- NO**
- Oil level too high
 - Oil level too low
 - Contaminated oil

YES - Go to STEP 7

7. **Cylinder Compression Inspection** – Check the cylinder compression

Is the engine compression normal?

- NO**
- Valve stuck open/seized or improper valve timing (see your local dealer)
 - Worn cylinder wall and/or piston rings (see your local dealer)
 - Leaking or damaged head gasket (see your local dealer)

YES - Go to STEP 8

8. **Over Heating Inspection** – Check the engine for overheating.

Is the engine overheating?

- NO** - Go to STEP 10
- YES**
- Excessive carbon buildup in the combustion chamber
 - Use of poor quality oil
 - Clutch slipping
 - Lean fuel mixture or improper octane rating of fuel

9. **Engine Condition Inspection** – Accelerate rapidly through all gears and ride at high speed

Does the engine knock?

- NO** - Go to STEP 11
- YES**
- Worn piston and cylinder (See your local dealer)
 - Wrong type of fuel (octane rating)
 - Lean fuel mixture
 - Excessive carbon buildup on the combustion chamber

10. **Ignition Timing Inspection** – Only attempt these procedures if you are qualified and have the proper tools needed. Otherwise, see your local dealer or a motorcycle repair shop to have the ignition timing and engine lubrication system inspected.

Is the ignition timing normal? (Timing is non-adjustable)

- NO**
- Faulty CDI ignition box
 - Faulty ignition pulse generator

YES - Go to STEP 12

TROUBLESHOOTING

12. **Lubrication Inspection** – Remove the valve adjustment covers on the cylinder head and inspect the system for lubrication.

Is the valve train being lubricated properly?

- NO** - Clogged oil passage (see your local Zuumav dealer)
- Dirty and/or contaminated engine oil
- YES** - See your local dealer to have your motorcycle serviced

POOR PERFORMANCE at IDLE and LOW SPEED

1. **Intake Manifold Inspection** – Check the intake manifold seals for leaks.

Is there a leak in the manifold?

- NO** - Go to STEP 2
- YES** - Loose carburetor mounting bolt (nuts)
- Damaged, cracked insulator/spacer
- Damaged intake manifold gasket
- Damaged O-ring seal
- Cracked or broken intake manifold (pipe)

2. **Spark Test** – Test for ignition spark by removing the spark plug and using a spark tester found at your local auto shop or by inserting it into the spark plug cap. Place the open end of the spark plug on a metal part of the engine and kick start the engine or use the electric start. You should see a nice blue spark on the end of the spark plug. A faint spark will not start the engine.

Is there a good spark?

- NO** - Fouled or faulty spark plug
- Broken or shorted spark plug wire or spark plug cap.
- Broken or shorted ignition coil
- Faulty ignition CDI box
- Faulty or shorted magneto assembly
- Broken or shorted engine stop switch
- Loose or corroded wires and/or connectors (always clean bad electrical connections)
- YES** - Go to STEP 3

TROUBLESHOOTING

4. **Ignition Timing Inspection** – See your local dealer or local motorcycle repair shop to have the ignition timing inspected. Only attempt these procedures if you are qualified and have the proper tools required.
- Is the ignition timing normal? (Timing is not adjustable)
- NO** - Faulty CDI ignition box
 - Faulty ignition pulse generator
- YES** - See your local dealer to have your motorcycle serviced

POOR PERFORMANCE at HIGH SPEED

1. **Ignition Timing & Valve Train inspection** –
to have the ignition timing inspected. Only attempt these procedures if you are qualified and have the proper tools required. See your local dealer or local motorcycle repair shop.
- Is the ignition timing, valve timing and valve springs normal? (Timing is non-adjustable)
- NO** - Faulty CDI ignition box
 - Faulty ignition pulse generator
 - Broken valve spring
 - Broken or damaged camshaft sprocket
- YES** - See your local dealer to have your motorcycle serviced.

TROUBLESHOOTING

POOR HANDLING

Steering is Heavy

- Steering stem nut is too tight
- Damaged steering head bearings
- Check tire pressure

Either Wheel Has a Wobble

- Excessive wheel bearing play
- Bent rim
- Improperly installed wheel hub
- Bent frame
- Loose or broken spokes
- Old tires with "dry-rot"
- Damaged swing-arm

The motorcycle pulls to one side

- Front and rear wheels out of alignment
- Damaged upper or lower triple clamp
- Damaged or bent fork(s)
- Bent swing-arm
- Bent frame
- Damaged or bent axle shaft

RESOLVING THE UNEXPECTED

GENERAL GUIDELINES

If you encounter trouble during a ride, the first thing you should do is stop as soon as it is safely possible. Do not continue to ride if you have a flat tire, if you hear an unusual noise, or if your motorcycle just does not feel right. If you continue to ride, you will cause more damage the motorcycle and endanger your own safety.

After you stop, take time to carefully look over your motorcycle and identify the problem. Always consider all of your options before you make a decision. Sometimes a problem can be relatively minor and can be permanently repaired on the trail provided you have the tools, supplies and skills needed to do so. In addition, you may be able to make a temporary repair and ride slowly back to your base where you can get further help and/or supplies.

When a problem appears to be more serious; or you do not have the tools, supplies and skills needed to make a repair, you will need to choose a safe way to get yourself and the motorcycle back to your base. If you are close enough, you can often push the motorcycle back.

Whatever the problem may be, always follow the instructions below:

1. Always put safety first.
 2. If the problem is minor and you have the tools, supplies and skills needed to make a temporary repair, be sure to make permanent repairs as soon as possible.
 3. Do not continue riding if you are hurt or if your motorcycle is not in safe riding condition.
- Recommendations for specific problems follow.

IF THE ENGINE QUILTS or WILL NOT START

If the engine was not making unusual noises before it quit running, and it feels normal when you operate the kick starter, you can probably rule out a major mechanical problem.

First, check the fuel system:

1. Make sure you have fuel in the gas tank and the fuel valve is set to the “ON” position.
2. Check the fuel tank cap breather hose to be sure it is not pinched or clogged.
3. Turn the fuel valve to the “OFF” position. Disconnect the fuel line from the carburetor and momentarily turn the fuel valve to “ON”. If fuel does not flow out, there is an obstruction in the fuel tank, fuel filter, or in the fuel line.

If the fuel system appears to be okay, check the ignition system.

1. Check the spark plug cap. Be sure that it is not loose or disconnected.
2. Disconnect the spark plug cap and remove the spark plug. Connect the spark plug to the plug cap and place the threaded end of the spark plug on a metal part of the engine.
3. Kick the kick starter while you watch the spark plug. If it sparks, the ignition system is probably working. If there is no spark, replace the spark plug with a new one. If there is still no spark, there is a problem with the ignition system.

If you cannot identify or correct a problem, you will have to push your motorcycle back to your base or get some help.

RESOLVING THE UNEXPECTED

IF YOU HAVE A FLAT TIRE

How you handle a flat tire on the trail will depend on the severity of the damage to the tire and/or the inner tube and what tools and supplies you keep with you. If you have a slow leak or a minor puncture, there are two ways you can try to make a temporary repair:

1. Use an aerosol tire sealer to seal the puncture and inflate the tube. You can do this without removing the wheel.
2. Use a tube repair kit to patch the hole in the inner tube. This requires removal of the wheel and tire.

If the leak is more severe, or a temporary repair does not hold up, you will need to replace the inner tube. If the tire is also severely damaged, you will need to replace the tire as well.

If you cannot repair the flat tire on the trail, you will need to push the motorcycle back to your base or send for help. Do not ride on a flat tire. The motorcycle will be hard to handle, and if the tire comes off the rim, it can lock up the wheel and cause you to crash.

IF YOU CRASH

Personal safety is the first priority after an accident. If you or anyone else has been injured, take plenty of time to assess the severity of the injuries and determine if it is safe to continue riding. If you cannot ride safely, send someone for help. Do not ride if you will risk further injury or if your motorcycle has been damaged too severely.

If you decide you are capable of riding safely, carefully inspect the motorcycle for damage. Check the tightness of critical nuts and bolts such as the handle bars, control levers, brakes and wheels. If there is minor damage, or you are not sure about possible damage but decide to ride back to your base, ride slowly and cautiously.

Sometimes crash damage is hidden or not immediately apparent. Once you get home, go over your motorcycle thoroughly and inspect the frame and suspension after a serious crash.


IF A COMPONENT FAILS

The drive chain, master link, control cables, brake controls, and other components can be damaged if you ride in dense brush or over rocky terrain. As mentioned earlier, making the repair on the trail will depend on the severity of the damage, tools, supplies, and skills that you have.

If the drive chain comes off because the master link clip has been knocked off, you may be able to repair the chain with a new master link. However, if the chain is broken or causes damage when it comes off, you may not be able to make a trailside repair. fix any problems that you find. Also ,be sure to have **your local dealer**.

If any component of the front braking system is damaged, you may be able to ride back to your base carefully using the rear brake for slowing and stopping. Likewise, if a component of the rear braking system fails, you can use the front brake for slowing and stopping.

If you damage the throttle cable or some other critical component, the motorcycle may be unsafe to ride. Carefully assess the damage and make any repairs that you can. But if you have any doubts, it is best to be conservative and safe.



EMISSION CONTROL SYSTEM WARRANTY

EMISSION CONTROL SYSTEM WARRANTY

Below is the emission control system warranty printed in the owner's manual, the copy of the owner's manual is available upon your request.

YOUR WARRANTY RIGHTS AND OBLIGATIONS

The U.S. Environmental Protection Agency, and **Zuma Extreme Sports Co.,Ltd.** (hereinafter "**Zuma Extreme Sports**") are pleased to explain the emission control system warranty on your 2024 Model Year OFMC. New vehicle must be designed, built and equipped to meet U.S. EPA Federal over the full useful life. Zuma Extreme Sports must warrant the emission control system on your vehicle for 5,000 km or for 30 months, whichever comes first, provided that there has been no abuse, neglect or improper maintenance of your vehicle.

Your emission control system may include parts such as the carburetor or fuel injection system, the ignition system, catalytic converter and engine computer, if it is equipped. Also included may be hoses, belts, connectors and other emission-related assemblies.

Where a warrantable condition exists, Zuma Extreme Sports will repair your vehicle at no cost to you, including diagnosis, parts and labor.

If an emission-related part on your vehicle is defective, the part will be repaired or replaced by Zuma Extreme Sports. This is your emission control system defects warranty.

NOTICE! Use of any Zuma Extreme Sports vehicles in any type of competitive event completely and absolutely voids this and all other warranties offered by Zuma Extreme Sports.

OWNER'S WARRANTY RESPONSIBILITIES

As the vehicle owner, you are responsible for the performance of the required maintenance listed in your owner's manual. Zuma Extreme Sports recommends that you retain all receipts covering maintenance on your vehicle, but Zuma Extreme Sports cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.

You are responsible for presenting your vehicle to the Zuma Extreme Sports's dealer as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.

As the vehicle owner, you should be aware that Zuma Extreme Sports may deny your warranty coverage if your vehicle or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

If you use your vehicle in any type of sanctioned competitive event, this warranty is immediately and completely void.

If you have any questions regarding your warranty rights and responsibilities, you should contact Zuma Extreme Sports Co.,Ltd., 1942 Broadway St.STE 314C,Boulder,CO 80302,TEL: 866-991-2128

Zuma Extreme Sports warrants that each new 2024 and later Zuma Extreme Sports's OFMC:

A. is designed, built and equipped so as to conform at the time of initial retail purchase with all

EMISSION CONTROL SYSTEM WARRANTY

applicable regulations of the United States Environmental Protection Agency, and

- B. is free from defects in material and workmanship which cause such vehicle to fail to conform with applicable regulations of the United States Environmental Protection Agency for the periods specified above.

- I. **Coverage.** Warranty defects shall be remedied during customary business hours at any authorized Zuma Extreme Sports's dealer located within the United States of America in compliance with the Clean Air Act and applicable regulations of the United States Environmental Protection Agency. Any part or parts replaced under this warranty shall become the property of Zuma Extreme Sports.

- II. **Limitations** This Emission Control System Warranty shall not cover any of the following:

- A. Repair or replacement as a result of

- (1) accident,
- (2) misuse,
- (3) repairs improperly performed or replacements improperly installed,
- (4) use of replacement parts or accessories not conforming to Zuma Extreme Sports's specifications which adversely affect performance and/or
- (5) use in competitive racing or related events.

- B. Inspections, replacement of parts and other services and adjustments required for required maintenance.

- C. Any vehicle equipped with an odometer or hour meter on which the odometer mileage or hour meter reading has been changed so that actual mileage cannot be readily determined.

- III. **Limited Liability**

- A. The liability of Zuma Extreme Sports under this emission control system warranty is limited solely to the remedying of defects in material or workmanship by an authorized Zuma Extreme Sports's dealer at its place of business during customary business hours. This warranty does not cover inconvenience or loss of use of the vehicle or transportation of the vehicle to or from the Zuma Extreme Sports's dealer. Zuma Extreme Sports shall not be liable for any other expenses, loss or damage, whether direct, incidental, consequential or exemplary arising in connection with the sale or use of or inability to use the vehicle for any purpose. Some states do not allow the exclusion or limitation of any incidental or consequential damages, so the above limitations may not apply to you.

- B. No express emission control system warranty is given by us except as specifically set forth herein. Any emission control system warranty implied by law, including any warranty of merchantability or fitness for a particular purpose, is limited to the express emission control system warranty terms stated in this warranty. The foregoing statements of warranty are exclusive and in line of all other remedies. Some states do not allow limitations on how long an implied warranty lasts so the above limitations may not apply to you.

- C. No dealer is authorized to modify this Zuma Extreme Sports Limited Emission Control System Warranty.

EMISSION CONTROL SYSTEM WARRANTY

IV. Legal Rights. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

V. This emission control system warranty is in addition to the standard limited warranty for all vehicles.

VI. Additional Information. Any replacement part that is equivalent in performance and durability may be used in the performance of any maintenance or repairs. However, Zuma Extreme Sports is not liable for these parts. The owner is responsible for the performance of all required maintenance. Such maintenance may be performed at a service establishment or by any individual. The warranty period begins on the date the motorcycle is delivered to an ultimate purchaser.